

# POWERMADD<sup>®</sup> Riser Block

## Non-Pivot Style

Installation Instructions for Part No. 15500 thru 15524

### HARDWARE INCLUDED:

<u>Qty</u>	<u>Description</u>
------------	--------------------

1	Riser Block
4	Bolts

**STEP 1:** Remove any handlebar pad or cover to expose the handlebar clamp.

**STEP 2:** Remove the four bolts that secure the clamp to the steering post.

**STEP 3:** Lift the handlebar assembly and clamp up off of the steering post plate and place the riser block on top of the plate.

**STEP 4:** Place the handlebar assembly and clamp on top of the riser block, line up the four holes and insert the four longer bolts included with the kit, making sure they go through both clamp halves, the riser block and the steering plate.

**NOTE:** You may have to cut cable ties and reroute brake line, throttle cable and wires to create enough slack required for the taller mounting position.

**STEP 5:** Reinstall the original lock nuts underneath the steering plate and tighten them evenly.

**STEP 6:** Reinstall any handlebar pad or cover they may have been removed in STEP 1.

**WARNING:** After installing the block, turn the handlebars fully left and right while checking for proper slack in the brake line, throttle cable and wires. Also re-secure any cables or wires of which you may have cut cable ties off of.

### LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

**POWERMADD<sup>®</sup>**

1-800-435-6881

[www.powermadd.com](http://www.powermadd.com)

WEB-INS-1 REV A