

## Method statement

### Dekguard E2000

#### Section A : General Comments

##### High temperature working

It is suggested that, for temperatures above 35<sup>0</sup>C, the following guidelines are adopted as good working practice:

- (i) Store unmixed materials in a cool (preferably temperature controlled) environment, avoiding exposure to direct sunlight.
- (ii) Keep equipment cool, arranging shade protection if necessary. It is especially important to keep cool those surfaces of the equipment which will come into direct contact with the material itself.
- (iii) Try to avoid application during the hottest times of the day, arrange temporary shading as necessary.
- (iv) Make sufficient material, plant and labour available to ensure that application is a continuous process.

##### Equipment

It is suggested that the following list of equipment is adopted as a minimum requirement.

<i>Protective clothing</i>	:	<i>Protective overalls</i>
	:	<i>Good quality gloves, goggles and face mask</i>
<i>Preparation equipment</i>	:	<i>Stiff wire brush</i>
	:	<i>Proprietary blasting equipment</i>
<i>Application equipment</i>	:	<i>Brush or roller</i>
	:	<i>Knapsack type spray equipment</i>

##### Application - points of note

Fosroc operates a policy to encourage the use, where possible, of approved or licensed applicators. This ensures that repairs are completed satisfactorily so that the long term performance of the materials is assured. For contractors who wish to apply the materials themselves Fosroc is also able to offer technical assistance and training, either on-site or at its Training Centre in Dubai

### Al Gurg Fosroc LLC

Post Box 657, Dubai  
United Arab Emirates

telephone:  
(+9714) 2039699

fax:  
(+9714) 2859649

email:  
[agf@fosroc.com](mailto:agf@fosroc.com)



*constructive solutions*

## **Section B : Application Method**

### **1.0 Preparation**

- 1.1 Clean all contamination such as oil, grease, algae, laitance etc from the surface by sweep blasting.
- 1.2 Carry out Biocide treatment after sweep blasting for areas where moss, algae or similar growths had occurred.
- 1.3 Fill all blowholes and other surface irregularities with Renderoc BF. Contact the local Fosroc office for further advice.
- 1.4 Protect areas of glass, plants, grass, joint sealants, asphalt and bitumen painted areas.

### **2.0 Priming**

- 2.1 Use a knapsack type spray equipment for applying Dekguard Primer DG and it will give a continuous and uniform surface appearance.
- 2.2 For extremely porous substrates, flood application of primer is recommended. Please contact local Fosroc office for advises on any priming queries.
- 2.3 Cure the primer for a minimum of 2 hours @ 20°C or 1 hour @ 35°C before over coating.

### **3.0 Application**

- 3.1 Apply Dekguard E2000 using airless spray equipment (Manual application by Roller or rush).
- 3.2 The first coat of Dekguard E2000 should be applied to all areas of the substrate to achieve uniform coating, with a w.f.t. of not less than 200 microns.
- 3.3 Allow the first coat to dry until firm to touch and then proceed with the application of the second coat. Also ensure by means of visual inspection that the surface is free of pin holes or any such irregularities, which if present should be filled with Dekguard Filler.
- 3.4 The second coat of Dekguard E2000 should be applied at 90° to the first ensuring that a final unbroken coating with minimum wft of 200 microns is achieved.

### **4.0 Cleaning**



*constructive solutions*

- 4.1 Cleaning with water will remove the Dekguard Filler from the tools and equipment.
- 4.2 Clean the tool's and equipment's with Fosroc Solvent 102 to remove Dekguard E2000 & Dekguard Primer DG.

### **Section C : Approval and variations**

This method statement is offered by Fosroc as a 'standard proposal' for the application of Dekguard E2000. It remains the responsibility of the Engineer to determine the correct method for any given application.

Where alternative methods are to be used, these must be submitted to Fosroc for approval, in writing, prior to commencement of any work. Fosroc will not accept responsibility or liability for variations to the above method statement under any other condition.