

UV254 Dip Go!



Issue Date: April 2019

About Us



Company Mission

Photonic Measurements are the experts in UV254. We can provide solutions for the measurement of UV254 in all applications within the drinking and waste water treatment, industrial effluent, receiving water and environmental testing, amongst others. Photonic Measurements range of UV254 products allow for the measurement of UV254 and its surrogates TOC, DOC, COD and BOD that fit your application needs.

The range of parameters/measurements that the company offers is expanding. Please visit www.PhotonicMeasurements.com for more information

Established in 2014, Photonic Measurements is located in Lisburn, Northern Ireland, UK.



Contents	Page No
Safety Advice	4
Introduction	5
Start-Up Guide	6
Guidelines for Use	8
Menu Screen	9
Data Screen	10
Measurement Routine	11
Measure Menu	12
Calibration Menu	14
Generate Curve	16
View Curve	19
Entering Equation	19
Calibration Example	20
View Equation	28
Settings Menu	29
Data Export	30
Care and Maintenance	32
Additional Parts	33
Ranges for Surrogates	34
Specifications	35
Glossary	36
Appendices	37
1. What is Absorption	37
Contact Us	44

Safety Advice

When using the UV254 Dip Go! please ensure you read the manual thoroughly and follow the instructions provided.

Ensure that all necessary equipment provided in the kit is of the standard described upon purchase.

Do not use this instrument for any other usage aside from what is instructed within the manual.

Please ensure that USB port is clean and dry prior to use, remove any object that could interfere with access to the charging port.

The UV254 Dip Go! does not require any specific cleaning for daily operation. However, a dry cloth can be used to collect dust. Do not use cleaning agents or solvents on the UV254 Dip Go!

Introduction

Photonic Measurements' UV254 Dip Go! is a light-weight, portable device, which allow easy measurement of open channel water. With rechargeable Li-ion battery applications the UV254 Dip Go!

- A simple icon-based user interface makes it easy to navigate between measuring, calibration and data collection.
- Long service life.
- Extensive storage capacity to preserve numerous measurements.
- Ability to generate graphical charts of data patterns.
- A USB port to connect and transfer data to your PC or Mac.
- Excel compatible, connect with device to examine data further.
- Ability to display up to four surrogate (Calibrated parameters) measurements simultaneously. For example, TOC (Total Organic Carbon).

Start-Up Guide



UV254 Dip Go! Start Up Guide




- 1. USB Charging Port with Cap
- 2. USB Charging Connection Socket
- 3. On/Off switch
- 4. Touchscreen Menu

Guidelines for Use Cleaning the Probe

The following steps should be used to ensure the Dip Go! is used correctly and efficiently to obtain accurate results.





Unscrew light shield to review the probe.



Clean the optical components around the probe. That is, the clear plastic and glass windows with a damp cloth and then dry

Menu Screen

The touchscreen menu allows the user to navigate simply through the four main sections of the analyser.



Allows the user to view collection of past measurement data.



Takes a UVT/UVA reading, and various surrogate measurements can also be taken.



Add parameters and create a profile for different water sampling points/locations.



Adjust time/date, power and brightness for power save.

Data Menu

Results collected will be stored on the device. Tens of thousands of results can be collected and stored for the duration of the analyser.

To view a result, select the year – you would like to review, and press Select

Continue by narrowing down your selection by choosing a month within that year.

All results obtained within that month will be displayed, select the day you wish to view. All results from that day will be displayed.


To see a plot of results of a period of time, choose one location and one parameter and then press the graph icon.

A graph will be displayed.

Press the grid icon to return to the table view of results.



File Date	Sample	Time	Parameter	Value	Units
07Mar00	Sample0	00	ADC	2500.0	mg/l
	Sample1	05:12:00	ABC	1.0	%
	Sample2	05:12:00	ABC	2.0	%
	Sample3	05:12:00	ABC	3.0	%
	Sample4	05:12:00	ABC	4.0	%
	Sample5	05:12:00	ABC	5.0	%
	Sample6	05:12:00	ABC	6.0	%
	Sample7	05:12:00	ABC	7.0	%
	Sample8	05:12:00	ABC	8.0	%



Measurement Routine

UVT/UVA- Is the measurement of Ultraviolet Transmission and Absorbance at 254nm.

SUVA- Provides a measurement in relation to EPA415.3 DOC Input from another device will be required for this method. (Please review the standard)


Locations- These can be acquired through user calibration of measurements of parameters/ surrogates that relate to UVA.

Measure Menu

Step 1:

Begin by selecting the Measurement Routine

For this example, we will select Location1




Step 2:

On a regular basis perform and reference measurement. This can be done by placing the probe/light shield in De-ionised water.




Click on Measure Reference and then on Yes



Step 3:

Place sample into Dip Go! and press measure.

To maintain accuracy, use the same cell that was used to take reference point



UVA/UVT are direct measurements


The list on the right-hand side is the user calibrated surrogate measurements

Calibration Menu

The calibrate menu button allows you to create a profile for a range of parameters known to respond to the changes in absorption at 254nm.


Enables you the ability to store these parameters from different sample points as the response can change from location to location.

Select a location you wish to calibrate; the name of the sample can be changed at a later stage.



User calibrated measurements of parameters/ surrogates that correlate to UV254 absorption. Parameters include; TOC, DOC, COD and BOD amongst others calibrated to UV254

Select a Parameter




At this stage if the parameter you selected is not there this can easily be adjusted by simply selecting the item you want to change.



This will also apply if you would like to modify, edit the location, parameter or units name, simple click on the blue box for each component.

When calibrating, four options will appear on screen like so:



1. Generate Curve

Step 1:


Generate Curve

After clicking Generate Curve,

Step 2:


Prepare a reference sample

Then press Reference



Step 3:

Leave reference sample in the Dip Go! and press Measure




Enter the concentration, for the reference cell it will be 0mg/L

Enter Value mg/l

Step 5:

The points will appear on the graph and the initial reference point (0.0mg/L)


When you are satisfied with your results from the calibration press Review



NOTE: Number of samples will be down to your own procedure.


Step 6:

In review check that the maximum value for the calibration is at the top end of the expected range




Click on the editable max value to change it.

Enter a new value if necessary



Step 7:


Click complete to save the calibration



2. View Curve

View Curve

The following graph will be displayed with the current calibration of the parameter selection.



3. Entering an Equation

Enter Equation

For calibration of parameters where the concentration is not known until a later date such as the measurement of BOD 5-Day. We must measure the water on the Dip Go! and record the values. On the sampling day, before the concentration from the primary device is known.

Once the concentration is discovered from the primary device. They can then be plotted in Excel and the coefficients found for the relationship. Finally, the coefficients can be entered onto the Dip Go! The following steps describe this process.

Example: Calibrate 5-Day BOD Test

To calibrate BOD on the Photonic Measurements, Dip Go! we recommend using BOD five-day test.

Take at least 3 samples of the water.

Measure the water a three different time periods on the Dip Go

Collect one sample each for the five-day BOD test.

(Three samples are needed to obtain enough statistical data to perform a calibration accurately.)

Ensure the samples are labelled to ensure the measurements from each sample can be correlated correctly.

Take three measurements at different time periods with the Dip Go



For each measurement collect a sample for the BOD reactor



3 Collected samples for BOD reactor

Measure BOD 5-Day


Perform the measurement of BOD using the procedure from the manufacturer of the five-day test. Once complete write the values into a table like so:

Sample Name	Value mg/L
Sample 1	BOD 5 Day measurement
Sample 2	BOD 5 Day measurement
Sample 3	BOD 5 Day measurement


Measure BOD on Dip Go!

Due to the five days test requirement for BOD you will need to measure the absorption of each of the three samples on the day, and then wait for the result to come in from the BOD five-day test. The reason we measure on the DIP GO! before the five-day test is to reduce any growth of organic material in the sample. Thus, instead of going to calibration we click on measurement to get the absorption. Start the Dip Go!

Select the Measure Screen



Click on UVT/UVA to get an absorption value




Measure Sample 1

Placing the Dip Go into the water that is to be measured. Measure the UVA value.


Take sample of water, to be measured with the 5-day BOD.

Repeat in a short time period, say 5 minutes until we have 3 measurements and 3 samples

Click Measure



Write down the UVA Value for Sample 1, as shown below in the table. The value 0.506 is used for example purposes only.



Sample Name	Value ABS
Sample 1	0.506
Sample 2	Enter UVA/Absorption value
Sample 3	Enter UVA/Absorption value

Continue this process for Sample 2 and Sample 3, then record values in the table. Lastly, when the 5-Day BOD test is complete, record each of the values.

Calculate the Calibration using Excel


Ensure that you put '0' for both measurements- this will help with creating a straight line.

	B	C
ABS	0	0
	0.506	33
	0.581	39
	0.426	28

Begin by opening a new spreadsheet and enter the data points collected from both the Dip Go! and BOD 5-day test.


	B	C
ABS	0	0
	0.506	33
	0.581	39
	0.426	28

Press Insert on the top menu bar in Excel to display data




	A	B	C	D	E
1		ABS	mg/L		
2		0	0		
3		0.506	33		
4		0.581	39		


When you press Insert across the menu bar
click Scatter Graph in Charts



A graph like this one
will appear



Right click one of the plotted points
and click on Add Trendline



A panel should appear with the following options, select linear curve

Exponential

Linear

Logarithmic

Polynomial Order 2

Power

Moving Average Period 2

Trendline Name

Automatic Linear (Series1)

Custom

Forecast

Forward 0.0 periods

Backward 0.0 periods

Set Intercept 0.0


Display Equation on chart

Display R-squared value on chart

Ensure to tick:

Set Intercept with 0.0 value

Display Equation on Chart



Input calibration data into the Dip Go!

The value displayed will be the B value of the equation

$Mg/L = A + (B \times UVA) + (C \times UVA^2)$ where A and C are zero.

The equation then forms the relationship between the UVA measurement of the Dip Go! and for example, BOD five-day results

Enter in your equation for example

Set A & C to zero and input the value of B found in excel

Change the Max Value of the measurement.

For example, if all three calibration points fall below what you expect the max range to be, then enter the max range of your water.

Lastly, to ensure the calibration is stored in the system. Press Save.

4. View Equation

View Equation

Your equation will appear in the fields on the screen for the given location and parameter.

Location: Location2 Parameter: TOC

Equation of form: Value = A + (B x Absorption) + (C x (Absorption)²)

A = B = C =


Max Value = mg/l



Settings Menu


Settings Menu will allow you to adjust certain screen preferences on the device.

Date and Time, can be found in this section by pressing the date button, simply scroll to find the correct date and press the Save button




Press System to adjust screen brightness and hours before reference warning. Managing the brightness will enhance the battery charge.

'Hours Before Reference Warning' simply means after a set time the system will alert you that a reference should be taken.



Information will provide the user with the analyser's software version number and serial number.




Data Export

The UV254 Dip Go! can be connected via USB cable to a PC or MAC. The Dip Go! will act like a USB flash drive by simply clicking into Documents on your device where it should appear on the left-hand side of the menu.

Settings > Info > USB Data Mode


To transfer data to your device, follow these steps: firstly, press to Settings on the Dip Go!




Press Info located at the bottom of the screen



Press USB Data Mode to begin the connection between the DIP GO! and your PC



To access a specific measurement, select the folder starting with the year and month the measurement was taken.




Access Data *.GO in Excel


Click File > Open > Browse > *.go > Enter

Type in *.go as below and click on file.



File name:



A menu bar will open complete the steps as follows: press Delimited



Then ensure tab, comma and other with a colon is ticked and press Finish



Care and Maintenance

Contact with water will not disrupt the use of the UV254 Dip Go! it will not damage the internal components. However, ensure that the device is dry before use.

The UV254 Dip Go! can be cleaned with a dust cloth as regularly as possible.

Battery and Storage

The internal battery is Lithium Polymer. it is recommended that the UV254 Dip Go! device be stored in temperatures between 5 and 27 degrees. Precautions should be taken when leaving the device in a car during extreme weather conditions.

Warranty and Disposal

The UV254 Dip Go! has a 2-year warranty, subject to use according to the manufacturer's instructions.

It is important to note upon disposal of the UV254 Dip Go! device – the Lithium Polymer battery must be fully discharged before taking the device to your local recycling facility.

Additional parts



1. Charger
2. Sample Container
3. Battery Bank
4. USB cable for export data and charging, kept underneath the controller

Ranges for Surrogates

Ranges for the Dip Go depend on the pathlength of the probe that was selected on purchase. Probes can be swapped out at to match the application, if the user has more than one probe.

Ranges

Parameter	1mm path length in mg/L	2mm path length in mg/L	5mm path length in mg/L	10mm path length in mg/L	20mm path length in mg/L	50mm path length in mg/L
COD	0-2800	0-1400	0-560	0-280	0-140	0-56
BOD	0-1400	0-700	0-280	0-140	0-70	0-28
TOC	0-1200	0-600	0-240	0-120	0-60	0-24
DOC	0-1000	0-500	0-200	0-100	0-50	0-20

Accuracy

Parameter	1mm path length in mg/L	2mm path length in mg/L	5mm path length in mg/L	10mm path length in mg/L	20mm path length in mg/L	50mm path length in mg/L
COD	4	2	0.8	0.4	0.2	0.08
BOD	2	1	0.4	0.2	0.1	0.04
TOC	2	1	0.4	0.2	0.1	0.04
DOC	2	1	0.4	0.2	0.1	0.04

Specification

Measurements	UVA, UVT and SUVA Surrogate measurements TOC, BOD, COD and others
Range	0-100% UVT 0-2.5 ABS
Accuracy	±0.5% UVT
Repeatability	±0.05% UVT
Path Length	20 or 50mm
Measurement Time	10 Seconds
Power	Internal Lithium Polymer Battery USB Charger
Wavelength	254nm LED and narrow filter photodiode
Light Source	Deep UV LED Long life, self-monitoring
Data Logger	Lifetime measurement storage.
Dimensions	DIP Probe: 95mm (d) 160mm (h) Display Unit: 150x180x77mm
Display	800 x 480 pixel 4in, Capacitive Touch, TFT colour LCD
Operating Conditions	10 to 45 °C, max 80% relative humidity (non-condensing)
Storage Conditions	-20 to 60 °C, max 80% relative humidity (non-condensing)
Enclosure Rating	Display Unit IP65
Probe Material	Plastic (food safe), Aluminium or Stainless Steel
Probe Rating	IP68
Interfaces	USB, Other options upon request
Warranty	2 years
Accessory Options	Hard Case, Cable Extender

Glossary

Total Organic Carbon (TOC)

(DOC + Suspended Organic Carbon = TOC)

TOC can come from a range of sources such as decaying natural organic material (NOM) and synthetic sources for example industrial chemicals. NOMs can react with chlorine and as a result can combine to cause harmful by-products

Dissolved Organic Carbon (DOC)

Part of TOC found in the water. It is the part that combines with chlorine to cause harmful by-products. DOC acts as a food source for bacterial and other microorganisms.

Biochemical Oxygen Demand (BOD)

A measurement of the amount of dissolved oxygen that is needed for aerobic biological organisms in a volume of water to breakdown the amount of organic material at a given temperature over a certain time period. This can be tested using the BOD 5-day test. For water being returned to the environment, the level of BOD is important to maintain aquatic life. Too low- there will be a lack of oxygen and too high- can result in suffocation of aquatic life.

Chemical Oxygen Demand (COD)

The amount of oxygen consumed over a given volume of given in mg/L. COD is different in that COD is the organic compounds that can be chemically oxidised.

Ultraviolet Transmission (UVT)

UVT is the measurement of UV energy at a wavelength or frequency which is transmitted through water

Ultraviolet Absorption (UVA)

UVA is the measurement of light that is absorbed by the sample.

Specific Ultraviolet Absorption (SUVA)

Provides a measurement in relation to EPA415.3 DOC Input from another device will be required for this method.

Surrogate

Is a substitute measurement.

Appendices

Appendix 1: What is Absorption

Absorbance is a measure of the amount of light that is absorbed by the sample.

The absorbance **value A = 2 - log – (T)**

Appendix 2: SUVA Measurement

Environmental agencies such as the EPA (method 415.3) use specific UV absorbance (SUVA) as a measurement for determining the disinfection by-product (DBP). The measurement is the ratio of absorption of UV254 to the dissolved organic carbon (DOC) concentration. The larger the SUVA the more of the total organic material is made up of aromatic organics. Aromatic organics are highly reactive with disinfectants and thus level of aromatics will greatly increase the risk of DBPs.

Contact Us


For more information, please contact us at:

3 Crescent Business Park

Lisburn

BT28 2GN

(+44) 02892106263



Follow us at:

 [phonic-measurements](#)

 [@Phonic_M](#)

 [@PhonicMeasurements](#)