

# Table of Contents

| Included in the box  | 2  |
|--|----|
| Charging Yorkie-Pro  | 3  |
| Backup (Trickle) Charging Procedure  | 4  |
| Main Measurement   | 5  |
| Yorkie-Pro Navigation Tree   | 6  |
| Features and Navigation  | 7  |
| Data Logging   | 7  |
| Main Menu  | 7  |
| Data Snapshot  | 7  |
| Battery Status   | 7  |
| Cellular Measurements  | 8  |
| Cellular Direction Finding   | 8  |
| Wi-Fi Measurements   | 9  |
| Wi-Fi Rogue AP Detection   | 10 |
| Detecting Cable Malware (O.MG)   | 11 |
| Wi-Fi Direction Finding  | 12 |
| Bluetooth/Bluetooth Low Energy Measurements                                  | 13 |
| About Bluetooth  | 14 |
| Bluetooth/Bluetooth Low Energy Direction Finding                             | 14 |
| Bluetooth/Bluetooth PairingBluetooth/Bluetooth/Bluetooth/Bluetooth/Bluetooth | 15 |
| Bluetooth/BLE Device Spoofing  | 15 |
| Bluetooth/BLE Frequency Analyzer   | 15 |
| About BLE Personal Trackers  | 16 |
| Locating BLE Personal Trackers   | 18 |
| Frequency Analysis   | 19 |
| Main Menu  | 20 |
| Vibrating Alert  | 20 |
| Audible Alert  | 20 |
| RF Scan Persistence  | 20 |
| GPS Status   | 20 |
| Battery Status   | 21 |
| Select Country   | 21 |
| Unit Information   | 22 |
| Data Logging   | 22 |
| Yorkie-Pro Product Safety Info   | 23 |
| Yorkie-Pro PC Software   | 24 |
| Dual Band Directional Patch Antenna Specifications                           | 31 |
| Low Pim Directional Antenna Specifications                                   | 33 |
| Omni Directional Ultra Wideband Paddle Antenna Specifications                | 36 |
| Omni Directional 2.4/5.8 GHz Antenna Specifications                          | 43 |
| GPS Antenna Setup Tips and Specifications                                    | 44 |
| GPS Receiver Data Sheet  | 45 |
| MSDS Rattery Safety Data Sheet   | 46 |

Yorkie-Pro ships inside its own rugged Pelican carrying case along with all accessories to get you going right away.

Included in box:

Pelican hard carrying/shipping case with space for accessories

Yorkie-Pro unit

charging base

AC power adapter with 110V AC power cable

USB-A to USB Mini 6' cable

2.4 / 5.8 GHz Wi-Fi/BT/BLE SMA omni-directional antenna

650-3000 MHz CW SMA omni-directional antenna

4.9-5.9 GHz CW SMA omni-directional antenna

2.4 / 5.8 GHz Wi-Fi/BT/BLE SMA directional patch antenna with 18" cable

650-3000 MHz CW SMA directional antenna including 18" cable

Before you start, completely charge up your Yorkie-Pro using the supplied AC/DC transformer and charging base. Note that the mini-USB port is for BVS factory use unless specified by your authorized BVS sales engineer or reseller.

Power up your Yorkie-Pro using the white, round button on the front of the unit just below the screen. The unit will immediately begin scanning but allow at least one minute after all antennae are attached for complete measurements of all nearby wireless energy.

You may power down Yorkie-Pro at any time by simply holding in the same round, white button for a few seconds and you see the screen power back down.

















#### **CHARGING YORKIE-PRO**

The primary method for charging the Yorkie-Pro wireless intrusion detector is by using the supplied charging cradle.

#### TO CHARGE:

Insert the Yorkie-Pro into the charging cradle.

Ensure the external transformer is plugged into an AC power outlet.

The GREEN light on the charging cradle will illuminate while the unit is charging.

**Error Indicator:** 

If the RED light illuminates at any point while the Yorkie-Pro is in the charging cradle, this indicates an error. In this case, remove the Yorkie-Pro, unplug the charger base, and contact BVS for technical support.

#### SECONDARY CHARGING METHOD

If you lose, misplace, or forget the charging cradle and/or external transformer, you can charge the Yorkie-Pro using a micro USB cable. This method provides a trickle charge, allowing the unit to operate and maintain battery life until it can be properly recharged in the charging cradle.

#### **BATTERY & CHARGING SPECIFICATIONS**

Charging Time: Approximately 5 hours for a full charge using the supplied charging cradle.

Runtime: Approximately 4 hours on a full charge/discharge cycle.

Battery: The Yorkie-Pro is powered by a high-capacity 5500mAh lithium battery.









#### BACKUP (TRICKLE) CHARGING PROCEDURE

If you lose or forget the Yorkie-Pro charger base or external charge transformer, follow these steps to charge the device using a standard micro-USB cable:

#### OBTAIN COMPATIBLE POWER ADAPTER

Use a wall adapter (USB power supply) with the following specifications:

Output Voltage: 5V DC

Output Current: 1.0 Amp (1000mA)

Ensure the adapter is certified for safe operation (UL, CE, or equivalent).

Use a Standard Micro-USB Cable

Connect a high-quality micro-USB cable to the USB charging port on the Yorkie-Pro. Avoid using low-quality or damaged cables, as they may affect charging efficiency. Plug Into a Reliable Power Source

Insert the USB adapter into a standard AC wall outlet.

Alternatively, a USB power bank with a 5V/1A output can be used for emergency charging. Charging Time Considerations

This trickle charge method will charge the Yorkie-Pro at a slower rate than the standard charging base. (Up to 24 hours)

Expect a longer charging duration to reach full capacity (charging time may vary depending on battery level).

#### **CHARGING INDICATOR & BATTERY STATUS**

The battery LED indicator on the Yorkie-Pro will illuminate to show charging status. Allow the device to charge fully before use to ensure optimal performance. Important Notes:

DO NOT use fast chargers (higher than 5V/1A) as they may damage the internal battery. This trickle charge method is for temporary use only and is not a replacement for the original charging base. For any further questions or technical support


#### **BATTERY REPLACEMENT & MAINTENANCE**

The internal rechargeable battery should only be replaced or upgraded by a factory-authorized technician. During battery replacement, the technician will:

Conduct a full battery test

Perform battery calibration to optimize performance.

For any charging issues or battery service, contact BVS technical support.







#### MAIN MEASUREMENT


This is the first and main Yorkie-Pro measurement screen users will see allowing a quick glance of all wireless activity. In this screen, independent thresholds can be set for cellular and Wi-Fi bands. Users can also drill down to one or all lists of all detected devices. Logging data, data snapshots and main menus can all be accessed from here too. A frequency and time domain analysis screen can only be accessed from here.

Top 6 strongest cellular frequencies are listed by channel number. Use UP/DOWN arrows to adjust threshold. Red signal strength bars indicate level above threshold and will trigger vibrating alerts depending upon alert settings. 'US' indicates United States cellular bands will only be detected. Yorkie-Pro ships from the factory with country's RF bands as indicated by the customer but you can change to your country of choice in the Main Menu settings. Please consult with BVS sales or support staff to verify that your unit can support your country before purchasing and also before you attempt to change the country in the MAIN MENU.


Displays entire 2.4 GHz Wi-Fi 14 channel band. Use UP/DOWN arrows to adjust threshold. Red signal strength bars indicate level above threshold and will trigger vibrating alerts depending upon alert settings.

Displays entire 5 GHz Wi-Fi band. Use UP/DOWN arrows to adjust threshold. Red signal strength bars indicate level above threshold and will trigger vibrating alerts depending upon alert settings.

Records all data shown on screen for export and review onto PC Navigates to Main Menu for all settings. Saves a single data snapshot and timestamps for export and review onto PC. Battery level indicator. Navigate to battery settings in main menu for more info.



Push this button to access cellular band and compare top 3 strongest signals received. Push this button to access a list of all Wi-Fi access points by signal strength and more information. Push this button to access a list of all Bluetooth and BLE (Bluetooth Low Energy) devices by signal strength and more information. Push this button to access the frequency analyzer screen which displays frequency and time domain graphs in 2.4 GHz band only.



Page 6

#### **FEATURES & NAVIGATION**

#### **BACK ARROW**

Use this arrow usually located on the upper left of the screen to navigate back to the previous screen. If it does not appear, then there is no previous screen.



#### DATA LOGGING

Touch this icon to begin logging data. The icon flashes to indicate measurements currently being seen on screen are also being recorded to the unit's internal flash storage. All data logs are time stamped using the Yorkie-Pro's internal GPS for precise time and positioning. Simply touch the icon again to stop data logging.



Internal storage allows for 5 unique data logging sessions at approximately 13MB per log file. Depending upon the screen being logged, the resulting data can be logged for a range of time. Use the countdown timer as an estimate for your security surveys. This data can then be downloaded from Yorkie-Pro to a PC for further analysis in any standard spreadsheet application. Check with your BVS sales or support representative for more information.

#### MAIN MENU

Touch this menu icon to enter the MAIN MENU settings from any screen. If you do not see this icon at the top of the screen, you are already in the MAIN MENU. Continue further into this user manual for a detailed breakdown of all settings.



#### DATA SNAPSHOT

Touch this camera icon to take a quick data snapshot of the on-screen data at anytime. Note: this does not take a screen image but rather it captures all visible measurements into a data snapshot. Yorkie-Pro can store up to 70 data snapshots internally.



This allows for convenient data points that can easily be integrated into a spreadsheet or report. All snapshots are time stamped using the Yorkie-Pro's internal GPS for precise time and positioning. These snapshots can then be downloaded from Yorkie-Pro to a PC for further analysis in any standard spreadsheet application.

#### **BATTERY STATUS**

This battery icon indicates the unit's remaining power at a glance. For estimated runtime and battery details, choose BATTERY STATUS in the MAIN MENU.



#### **CELLULAR MEASUREMENTS**

This screen displays the 3 highest cellular signal strength measurements in dBm, frequency and cellular channel allocation from moment to moment. This means that the top 3 strongest signals displayed can quickly change if any newer, stronger cellular signals are then detected. This allows users to dynamically sweep the area for the strongest (usually the closest too) signals in real time.

Choose SHIFT SCALE to dynamically shift the dBm measurement scale between 0 dBm to -50 dBm and -40 dBm to -90 dBm. SCALE SHIFT allows users to effectively "zoom in" or "zoom out" on signals that are too visibly low or too high respectively.

The threshold is also adjustable allowing for vibrating alerts when any one or all of the signals break that threshold. When a vertical signal strength measurement bar is greater than the threshold setting, the area above the threshold turns red. Touch the up or down ADJUST THRESH arrows to adjust the threshold. Lowering the threshold (touching down arrow) is useful for detecting and alerting users to lower strength measurements. Raising the threshold (touching up arrow) is useful for detecting and alerting users to higher strength measurements.


Each vertical signal strength bar displays a high watermark indicating the maximum signal strength detected. This peak signal strength can indicate a great change in signal strength over time that cannot be seen by simply looking at this screen momentarily. The watermark timer is settings are located at the top of the screen and can reset the watermark every 5 or 30 seconds automatically.


Users who wish to pick a single measurement for further surveying and direction finding can simply touch the one of interest to enter the CELLULAR DIRECTION FINDING screen.

#### **CELLULAR DIRECTION FINDING**

This screen allows users to locate a cellular device being measured by replacing the standard omni-directional antenna with the optional direction finding antenna and using the real time signal strength scales. The color-coded scale on the left is measured in a range from -30 dBm to -80 dBm. Each colored bar represent 5 dBm. The stronger the signal, the greater the number of bars that are shown. Before you begin direction finding, replace the small omni-directional antenna with the larger directional at the middle SMA antenna connection (650 MHz - 3000 MHz) on top of the Yorkie-Pro unit.

As you sweep, the colored bar will guide you in the direction of the cellular signal source by lowering and raising accordingly. When the colored bars are at their maximum height, you can utilize the scale to the right to view further signal strength details in dBm. The top half of this scale (starting at 0 and ending in 5) corresponds to 5 dBm which is also the size of a single colored block on the left so the scale on the right effectively magnifies the top portion of the scale on the left.





Once the direction finding antenna is pointing in the direction of the highest signal strength, you can begin to locate the phone being detected by slowly walking in that direction. If you see the signal strength drop, simply stop moving and rotate in place just as you did before until the strongest signal strength is again displayed. Continue moving in the direction that the directional antenna is now pointing and repeat these steps until you reach the source.

You can return to the previous screen at any time by touching the back arrow on the upper left side of the screen. From there you can try to locate the same cellular source again or choose a different one. Just remember to replace the direction finding antenna with the omni-directional antenna when you are not in the direction finding screen or your RF surveys will not be accurate.

#### WI-FI MEASUREMENTS

Starting from the MAIN MEASUREMENT screen, touch the Wi-Fi icon located on the bottom to scan all nearby Wi-Fi access points. This screen indicates MAC address, RSSI signal strength in dBm, 802.11 channel number and SSID of every 2.4 GHz and 5 GHz access point detected. Orange colored SSIDs indicate 2.4 Ghz and yellow SSIDs indicate 5 GHz. Yorkie-Pro will not detect any client Wi-Fi devices.

Depending upon the number of access points and their activity, you might see the list updating very frequently or not frequently at all. The strongest Wi-Fi access point will move to the top of the list followed by the next strongest one and so on, but if you find the list too long or changing too frequently you can adjust the RF SCAN PERSISTENCE in the MAIN MENU settings. RF SCAN PERSISTENCE does not affect measurements, it only affects how long measurements remain on the screen after a signal is lost. The choices include ALWAYS ON, ALWAYS OFF, 10 SECS and 10 MINS. You might need to experiment with these settings depending upon your environment but BVS recommends 10 SECS for most busy RF environments and 10 MINS for less busy RF environments.

WI-FI MEASUREMENT screen includes sorting and navigation buttons on the bottom. Touch the up or down PAGE arrows in the lower right of the screen to navigate through the pages of APs and their respective measurements

The WHITE LIST button allows users to remove known access points from the list. This feature allows users to spend more time identifying unknown and possibly dangerous rogue APs instead of continually sorting through access points that have already been scanned and accounted for. Simply touch this button to activate this feature (the button will invert to indicate activation). Next, touch each listed Wi-Fi device that you wish to white list. Every AP you choose will disappear from the list and not return until the unit power is reset or until you choose to reset your white list. Touch the WHITE LIST button again when you are finished white listing access points.

RESET WHITE LIST button simply resets the white list of removed access points. Touch this button to reset the list.







#### WI-FI ROGUE AP DETECTION

A Rogue Access Point (AP) is any wireless access point that exists on a network without the authorization of the network administrator. These roque APs pose significant risks to a company's cybersecurity posture:

Data Interception (Man-in-the-Middle Attacks): Rogue APs can intercept sensitive company data, including login credentials, confidential files, and communication. Cybercriminals can set up malicious APs designed to mimic legitimate company networks, tricking employees into connecting to them.

Network Breach and Malware Deployment: Attackers can use rogue APs to bypass corporate firewalls and security controls, gaining unauthorized access to the internal network. Once inside, they can deploy malware, ransomware, or spyware.

Credential Theft and Phishing: Employees connecting to rogue APs may unknowingly enter their login credentials, which can then be harvested by attackers. Rogue APs can also serve phishing websites or inject malicious code into legitimate sites.

Compliance Violations: Unauthorized APs may compromise data protection regulations, such as GDPR, HIPAA, or PCI DSS, leading to legal consequences, fines, and reputational damage.

Denial of Service (DoS) Risks: Rogue APs can degrade legitimate network performance or launch denial-of-service attacks, disrupting operations.

#### WHY YORKIE-PRO IS ESSENTIAL FOR DETECTING ROGUE APS?

The Yorkie Pro wireless intrusion detector is a critical tool for security audits and sweeps because of its ability to:

Accurate Rogue AP Detection: Yorkie-Pro can detect and locate unauthorized access points by identifying suspicious wireless signals and comparing them against known authorized devices.

Real-Time Threat Identification: Its real-time scanning capabilities ensure that rogue APs are identified as soon as they appear on the network, minimizing the time attackers have to exploit vulnerabilities.

Wide Spectrum Coverage: Yorkie-Pro can scan multiple wireless frequencies (Wi-Fi, Bluetooth, BLE) and pinpoint threats from a wide range of rogue devices.

Portable and User-Friendly Design: Its compact, portable design allows security teams to conduct regular on-site sweeps easily, covering even large facilities.

Proactive Security Posture: Routine audits using the Yorkie-Pro help organizations maintain a proactive security posture, identifying vulnerabilities before attackers can exploit them.

Potential Threats to a Company's Cybersecurity Posture

Failing to address rogue APs can lead to:

- Loss of Intellectual Property: Sensitive data can be exfiltrated through unsecured rogue APs.
- Reputational Damage: A data breach linked to a roque AP can erode trust among clients and stakeholders.
- Financial Impact: Costs related to legal actions, fines, incident response, and downtime can be significant.
- Reduced Employee Productivity: Network instability caused by rogue AP interference can disrupt business operations.

By integrating tools like the Yorkie-Pro into regular security routines, companies can bolster their defenses, prevent unauthorized access, and safeguard their networks against rogue AP threats. If you are looking to specifically hunt down Wi-Fi clients/STA's then consider the companion offering; the Yellowjacket-Pro WiFi security tool.

The Yorkie-Pro wireless intrusion detector is highly effective in detecting and locating O.MG bad cables that have integrated Wi-Fi capabilities and function as covert hotspots for deploying malicious payloads. These malicious cables appear as standard USB or Lightning cables but house embedded chips that create rogue Wi-Fi access points, allowing attackers to wirelessly execute payloads, steal data, or maintain persistent access to compromised systems.

#### How Yorkie-Pro Detects O.MG Cables:

- 1. RF Signal Detection The Yorkie-Pro continuously scans for unauthorized or suspicious Wi-Fi signals (2.4 GHz, 5 GHz), identifying rogue access points created by compromised cables. The O.MG bad cable acts as a WiFi AP Hot Spot.
- 2. SSID and MAC Address Analysis The device can recognize anomalous SSID broadcasts or unauthorized MAC addresses, which often appear with randomization tactics that differ from facility-approved networks.
- 3. Signal Strength Direction Finding Once an unauthorized signal is detected, Yorkie-Pro enables direction-finding mode to pinpoint the exact location of the O.MG cable by following its RF emissions.
- 4. Automated Alerts & Logging Yorkie-Pro can integrate with security monitoring systems to alert personnel in real-time and provide detailed logs of the detected threat.

#### Why This Threat is Critical for US DoD & Other Secure Facilities


- Covert Exfiltration An attacker with brief physical access can replace legitimate cables with O.MG cables, which then serve as remote access backdoors, potentially leaking sensitive data from classified systems.
- Bypasses Traditional Security These malicious cables operate outside of traditional network defenses since they establish their own Wi-Fi hotspots, making them difficult to detect without RF surveillance.
- Air-Gapped Facility Risk Even secure air-gapped environments are vulnerable if a compromised cable is introduced internally, bridging the gap between isolated systems and external attackers.
- Insider Threat & Supply Chain Attacks The introduction of these devices can be intentional (insider threat) or unintentional (compromised supply chain), making regular RF sweeps essential to counter emerging threats.

#### The Need for Routine Yorkie-Pro Scanning

Given the rapid evolution of wireless attack vectors, DoD and other high-security facilities must implement frequent RF sweeps with the Yorkie-Pro to detect:

- Emerging Wi-Fi-based threats, including unauthorized IoT devices and bad cables.
- New roque signals in secure areas that should not have any wireless activity.
- Hidden access points that evade conventional Wi-Fi security tools.

By integrating Yorkie-Pro into daily or weekly security sweeps, facilities can proactively identify and mitigate wireless threats like O.MG cables before they lead to catastrophic security breaches.





This O.MG cable contains a Wi-Fi chip capable of delivering malware directly to any device it is plugged into. It is visibly indistignuishable from any regular USB-C cable but Yorkie-Pro can detect it.

#### WI-FI DIRECTION FINDING

Once you have identified a Wi-Fi access point of interest, you can begin to locate it by choosing it from the Wi-Fi MEASUREMENT list screen. That takes you to the WI-FI DIRECTION FINDING screen seen here. This screen scans only the AP selected from the previous screen. If you require a full Wi-Fi scan of all channels or Wi-Fi RF energy profile, use the BACK ARROW to return to the MAIN MEASUREMENT screen.

In addition to Wi-Fi RSSI measurements in dBm, the WI-FI DIRECTION FINDING screen also displays the MAC address, and SSID of the access point.

Replace the omni-directional antenna with the large, 2.4/5.8 GHz DF antenna by connecting to the SMA connector on the left side atop the Yorkie-Pro unit.

From the Wi-Fi MEASUREMENT list screen, touch the device you wish to locate. This will take you to the Wi-Fi Direction Finding screen. This screen displays the device's signal strength in dBm in both numerical and graphical form. The scale on the left goes from -30 dBm to -130 dBm. The lower the number, the higher the signal strength. Graphically, the higher the signal strength detected, the higher the color-coded blocks will appear. Red to orange blocks are high signal strength, yellow to green are medium signal strength and blue to purple are low signal strengths. A high signal strength generally indicates that the device being scanned is nearby and in the same direction that the direction finding patch antenna is pointing at that moment. If the signal strength is stronger than -30, it will appear as red and blinking at the bottom.


The scale on the right is a more granular scale for dBm within each color-coded block. The signal strength bar to the right should always match the color of the color-coded block being displayed on the left. The RSSI number at the bottom (in dBm) should also correlate to the signal strength currently being show. Due to some factors such as interference and movement during direction finding performed by the user, these numbers and color-coded blocks can shift abruptly.

Users trying to locate any device while direction finding need to move slowly and methodically always keeping the position and direction of the handheld antenna in mind. Once the direction finding antenna is attached to the Yorkie-Pro the position or direction of the unit itself has no bearing on the measurements being taken. Once the omni-directional antenna is connected back to the Yorkie-Pro receiver, the position and direction of the unit itself will have some bearing on the measurements taken again.

Begin direction finding by slowly sweeping the area in a full 360 degrees. Note the direction you are facing when you see the strongest signals. Next, you can break the 360 degree sweep into halves or quarters and concentrate the next sweep on just the half or quarter(s) that showed the strongest signals. Move into the direction of the strongest signals and continue sweeping slowly until you reach the highest signal strength. If the DF antenna is held too closely to the measured device, it can overload the receiver and display a measurement of -120 dBm in white at the bottom of the screen.







#### **BLUETOOTH MEASUREMENTS**

Starting from the MAIN MEASUREMENT screen, touch the Wi-Fi icon located on the bottom to scan all nearby Bluetooth and BLE (Bluetooth Low Energy) devices. This screen indicates MAC address, Device ID and RSSI signal strength in dBm of every BT and BLE device detected. White colored MAC and device IDs (friendly names) indicate BT but light blue colored MAC and device IDs (friendly names) indicate BLE devices.

Depending upon the number of devices and their activity, you might see the list updating very frequently or not frequently at all. The strongest BT or BLE device will move to the top of the list followed by the next strongest one and so on, but if you find the list too long or changing too frequently you can adjust the RF SCAN PERSISTENCE in the MAIN MENU settings. RF SCAN PERSISTENCE does not affect measurements, it only affects how long measurements remain on the screen after a signal is lost. The choices include ALWAYS ON, ALWAYS OFF, 10 SECS and 10 MINS. You might need to experiment with these settings depending upon your environment but BVS recommends 10 SECS for most busy RF environments and 10 MINS for less busy RF environments.

BLUETOOTH MEASUREMENTS screen includes sorting and navigation buttons on the bottom. Touch the up or down PAGE arrows in the lower right of the screen to navigate through the pages of devices and their respective measurements.

BLE ONLY/BLE+BT TOGGLE is a two-way button that either displays only nearby BLE devices detected or all nearby BLE and BT devices detected. Since there are so many BT and BLE devices already in use, some users need to view only BLE devices, specifically hidden personal trackers. This toggle disappears when the BLE TAG SORT is checked on in the MAIN MENU screen.

PERSONAL TRACKERS are among the cheapest and most ubiquitous devices around. They are also elusive to most BLE receivers. Yorkie-Pro utilizes a special algorithm to detect hidden BLE trackers (including Apple AirTag®, Samsung Galaxy SmartTag®, Tile Tracker®, etc.) immediately without the need to wait for warning notifications from your phone that you are in the vicinity of an unknown tracker. BLE MAC addresses shown in YELLOW have been identified as possible BLE trackers. BLE MAC addresses in RED have a much higher confidence identification of unknown personal trackers.

The WHITE LIST button allows users to remove known devices from the list. This feature allows users to spend more time identifying unknown and possibly dangerous rogue BT or BLE devices instead of continually sorting through devices that have already been scanned and accounted for. Simply touch this button to activate this feature (the button will invert to indicate activation). Next, touch each listed Wi-Fi device that you wish to white list. Every AP you choose will disappear from the list and not return until the unit power is reset or until you choose to reset your white list. Touch the WHITE LIST button again when you are finished whitelisting devices.

16:AD:8E:71:15 CHIPOLO 8:00:DB:0D:A1:17 6:AD:8E:71:15 -86 TRACKER 18:00:DB:0D:A1:17 FITBIT FLEX C0:CE:CD:E6:00:26 -103 PAGE 10 button to reset the list.

#### **About Bluetooth and BLE**

Bluetooth is a wireless technology standard for exchanging data over short distances (using short-wavelength UHF radio waves in the 2.4 GHz ISM band) from fixed and mobile devices, and building personal area networks (PANs). The Bluetooth protocol is active in over tens of billions of devices worldwide. Bluetooth technology, combined with a lower cost of entry, has enabled business cases for applications that were previously unthinkable.

BLE devices follow the Bluetooth standard. They manage their power by automatically powering up and down while remaining connected to the reader infrastructure (smart connectivity). Compared to previous versions, BLE enables 250% faster and more reliable over-the-air data transmission and 10x more packet capacity. The job of BLE is to drive the 'Internet of Things' (IoT), namely the thousands of smart, web connected devices – from fridges to toothbrushes – that are expected to enter our lives over the next decade.

#### **BLUETOOTH/BLE DIRECTION FINDING**


Once you have identified a Bluetooth or Bluetooth Low Energy device of interest, you can begin to locate it by choosing it from the BT/BLE MEASUREMENT list screen. That takes you to the BT/BLE DIRECTION FINDING screen seen here. This screen scans only the device selected from the previous screen. If you require a full BT/BLE scan of all nearby devices, use the BACK ARROW to return to the MAIN MEASUREMENT screen. In addition to BT/BLE RSSI measurements in dBm, the BT/BLE DIRECTION FINDING screen also displays the MAC address, and device ID of the device.

Replace the omni-directional antenna with the large, 2.4/5.8 GHz DF antenna by connecting to the SMA connector on the left side atop the Yorkie-Pro unit.

#### **BLUETOOTH/BLUETOOTH PAIRING**

Some BT/BLE devices allow pairing with Yorkie-Pro's internal BT/BLE module. This pairing is dependent upon the BT/BLE device settings and cannot be controlled or guaranteed by Yorkie-Pro. When this happens, a blue chain icon will appear in the lower left corner of the direction finding screen. You may notice a speed increase in the direction finding screen's update rate during this time due to the nature of BT/BLE pairing.

From the BT/BLE MEASUREMENT list screen, touch the device you wish to locate. This will take you to the BT/BLE Direction Finding screen. This screen displays the device's signal strength in dBm in both numerical and graphical form. The scale on the left goes from -30 dBm to -130 dBm. The lower the number, the higher the signal strength. Graphically, the higher the signal strength detected, the higher the color-coded blocks will appear. Red to orange blocks are high signal strength, yellow to green are medium signal strength and blue to purple are low signal strengths. A high signal strength generally indicates that the device being scanned is nearby and in the same direction that the direction finding patch antenna is pointing to at that moment. If the signal strength is stronger than -30, it will appear as red and blinking at the bottom.





The scale on the right is a more granular scale for dBm within each color-coded block. The signal strength bar to the right should always match the color of the color-coded block being displayed on the left. The RSSI number at the bottom (in dBm) should also correlate to the signal strength currently being show. Due to some factors such as interference and movement during direction finding performed by the user, these numbers and color-coded blocks can shift abruptly.

Users trying to locate any device while direction finding need to move slowly and methodically always keeping the position and direction of the handheld antenna in mind. Once the direction finding antenna is attached to the Yorkie-Pro the position or direction of the unit itself has no bearing on the measurements being taken. Once the omni-directional antenna is connected back to the Yorkie-Pro receiver, the position and direction of the unit itself will have some bearing on the measurements taken again.

Begin direction finding by slowly sweeping the area in a full 360 degrees. Note the direction you are facing when you see the strongest signals. Next, you can break the 360 degree sweep into halves or quarters and concentrate the next sweep on just the half or quarter(s) that showed the strongest signals. Move into the direction of the strongest signals and continue sweeping slowly until you reach the highest signal strength. If the DF antenna is held too closely to the measured device, it can overload the receiver and display a measurement of -120 dBm in white at the bottom of the screen.


### **BLUETOOTH/BLE DEVICE SPOOFING**

MAC address randomization is a process of generating MAC addresses that cannot be traced back to a specific device. MAC addresses are randomly generated and changed periodically, making it difficult for someone to track down a specific device. Many smartphones, Wi-Fi and BLE devices utilize MAC and Device ID spoofing to maintain user privacy. These spoofing randomizations usually occur about every 15 minutes (varies by manufacturer) but Yorkie-Pro can detect these changes and alert users to them.

The red and black "!" next to any device ID indicates a possible MAC spoof. If you choose one of these devices from the list, the direction finding screen will also display "POSSIBLE MAC ADDRESS SPOOF" at the top as well. Learn more about spoofing in the steps for Locating BLE Personal Trackers that follows this page.

#### BT/BLE FREQUENCY ANALYZER

This frequency analyzer (button with blue outline) measures the 3 advertising channels (37, 38 and 39) in the BT and BLE spectrum. Users can adjust the time domain at the bottom between 1, 4 and 10 seconds for each scan. This frequency analyzer mode differs slightly from the regular frequency analyzer mode (button with red outline) used in the MAIN MEASURMENT screen.



#### **About BLE Personal Trackers**

Yorkie-Pro detects frequencies used by both cellular GPS trackers and BLE (Bluetooth Low Energy) personal trackers such as AirTags, Galaxy Smart Tags, Tile Trackers, Chipolo, PebbleBee and others. For precise cellular GPS tracker detection and location features, ask your BVS sales engineer about Wolfhound-Pro. For detection of BLE personal trackers, Yorkie-Pro contains special features described in the following text, but first a brief background on BLE personal trackers.

Back in 2013, Tile launched their first BT (Bluetooth) based keyfinders. Over the years, they've improved the product line and added a Tile Network that leverages the GPS in every smartphone to help users locate a variety of lost items. These trackers (including all modern personal trackers) are relatively small, inexpensive and have a long battery life lasting around a year. All of these products required users to install an app on their Android or iOS devices so marketshare was limited but that all changed once Apple introduced their AirTag back in 2021. Since Apple has shipped well over 1.5 billion iOS devices that include their 'Find My' app pre-installed and integrated into their iOS, AirTags gain an immediate advantage over all personal trackers because every iOS user in the world automatically participates in finding lost items using AirTags. Other popular BLE trackers are on the market including Samung Galaxy Smart Tags and Tile Trackers but they are all similar so for this discussion, we will only be dealing with AirTags since they are the most popular for both good and not-so-good reasons that we will discuss shortly.

Since iOS devices are popular around the world, Apple's Find My network is able to identify AirTags around the globe. The primary limitation for AirTag discovery is the range of the BLE radio beacon in every AirTag. Since BLE is limited to about 100 meters, if there is no iOS device in that range, the AirTag will not be seen on the Find My network until an iOS device is nearby. In order to save battery life, AirTags do not continuously emit a BLE beacon so if an iOS device leaves the AirTag's range too soon after arriving, it will not be discovered on the Find My network either. Nevertheless, AirTags can usually be located by their users reliably and quickly from the other side of the world. AirTags also utilize an UWB (Ultra WideBand) chip that works in the 6.5-8 GHz range for short range direction finding (typically 15 feet or less) and an NFC (Near Field Communications) chip that works at 13.56 MHz for initial AirTag setup out of the box, but without a 2.4 GHz BLE connection to a nearby iOS device, an AirTag will not be discoverable on the Find My network.

Soon after AirTags arrived on the scene, problems were being reported by users involving illegal stalking and tracking of people and items without their knowledge. Apple foresaw some of these problems before they released AirTags by including "unwanted tracking" technology warnings for users. If an unknown AirTag has been hidden inside a vehicle or in someone's bag, the AirTag will eventually emit an audible chime and also send a notification to the user's iOS device that they are being tracked by a nearby, unknown AirTag. However, some users reported to only receive unwanted tracking warnings days after the tracking began and others complained that the alert chime was too faint to hear in most scenarios. In 2022, Apple updated all AirTags to include a more audibly discernible chime but the amount of time from the beginning of unwanted tracking to the moment of notification is a much more complex issue. Tech enthusiasts have added











to the mix by modifying and selling "silent' AirTags on Etsy and Ebay. These are simply AirTags that have been modified so that no audible tone can be heard. This makes detection of hidden AirTags even more difficult for the average consumer and since they are being sold as a remedy to thieves who can easily hear and remove hidden AirTags on items they just stole, 'silent' AirTags are not being labelled as illegal so they continue to be sold.

Since many users hide AirTags inside valuable items to track them, the faster the Find My network alerts users to the possibility of unwanted tracking, the more likely thieves who've stolen trackable items will be informed that they contain an AirTag. From there, thieves can simply locate and remove the AirTag frustrating honest users. If unwanted tracking notifications takes too long to warn users, it might be too late for victims of stalking or theft. Couple this balancing act with the fact that Apple has implemented specific algorithms that respond to AirTag movement, proximity to owners and other iOS devices and you end up with an unpredictable notification system at best and a dangerous and illegal stalking or tracking tool at worst.

Law enforcement agents have already responded to thousands of reports of unwanted tracking but that is only because users have already been notified of an unknown, nearby AirTag. AirTags continue to be used to track police vehicles, track packages of illegal substances and the whereabouts of high profile individuals and their families. Law enforcement agents have managed to successfully detect hidden cellular GPS trackers since they transmit at regular intervals when in motion but personal BLE trackers are more complex to identify and locate. Since AirTags do not immediately alert users to nearby unwanted tracking, there is no fast and easy way for anyone to detect a hidden AirTag without waiting hours or possibly days until they receive a warning notification. This is not acceptable to any law enforcement agent that requires immediate actionable intelligence. Yorkie-Pro solves this problem. Use the following steps on the next page to practice detecting the tracker included with your unit.





#### **Locating BLE Personal Trackers**

In order to help users better understand how to locate personal trackers, we have included an Apple AirTag to get you started. Be sure to follow all of the respective manufacturers' setup steps unless instructed otherwise by these following steps.

- 1. Unpack and register your included tracker by activating it and following the instructions included from the manufactruer of the respective tracker.
- 2. After you have initialized your tracker and are ready to practice detecting it using Yorkie-Pro, be sure to turn OFF your phone or put it into airplane mode making sure the BT radio is off as well (some phones do not include BT in airplane mode). Otherwise, that tag cannot be detected.
- 3. Be sure that all included omni-directional antennas are connected to the Yorkie-Pro.
- 4. Enter the Main Menu Settings and make sure that the 'BLE Tag Sort' box is checked.
- 5. While in the Main Menu Settings, set RF Scan Persistence to 'Always Off'. This will ensure that all trackers present will be seen as they appear and that trackers no longer active or in range will not appear. Since you are only testing your tracker detection feature at this stage, you will be keeping a close watch on a single tracker so 'Always Off' is a useful setting.

When you begin to operate Yorkie-Pro in unknown environments with varying degrees of BT and BLE activity, you will need to experiment with different RF Scan Persistence settings to minimize your time spent surveying. For instance, if you leave RF Scan Persistence 'Always On' in a busy environment, the list of devices will grow quickly and you will eventually see the spoof icon (exclamation point surrounded by red) for some devices indicating that those MAC addresses are being spoofed and no longer being used by those devices. Navigate back to the Main Measurement Screen and enter the Bluetooth Measurement screen.

6. In Bluetooth Measurement screen, the tracker should appear within a minute or so and the RSSI value should remain relatively stable unless the distance from Yorkie-Pro to the tracker changes. The MAC address will initially appear in yellow to indicate that a tracker has likely been detected. Once Yorkie-Pro fully verifies tracker detection, the MAC address will turn red.

Each tracker manufacturer has their own timing assigned to this advertising beacon. For example, Apple AirTags can take up to 20 minutes for the MAC address to turn from yellow (lower confidence) to red (high confidence) to indicate tracker identification certainty while Samsung's Galaxy Smart Tags are immediately identified as such (MAC address is red) as soon as they are detected. It can be helpful to note these time variations with each new manufacturer and their respective tracker models that you detect using Yorkie-Pro as it will help anticipate survey times for future surveys.













#### FREQUENCY ANALYSIS

The FREQUENCY ANALYSIS screen can only be accessed from the MAIN MEASUREMENT screen. It consists of 2 different panels that both scan the 2.4 GHz spectrum but do not display live data simultaneously. The orange panel on top is a frequency domain that scans 20 MHz chunks starting at the center of each of the (14) 802.11b/g channels. The yellow panel on the bottom is a time domain that samples a single frequency (same as center frequency in the top panel) over a selectable time interval.

Touch the top panel to begin scanning by frequency. If the time domain panel below was active, it will freeze during the frequency domain scan. Move along the spectrum in 20 MHz chunks by touching the left or right yellow arrows on the green top panel. Adjust the dBm scale by touching the up and down yellow arrows on the left side of the orange top panel just below.

Touch the bottom yellow panel to activate the time domain scan. If the frequency domain panel above was active, it will freeze during the time domain scan. Move along the spectrum in 20 MHz chunks by touching the left or right yellow arrows on the green top panel. Adjust the dBm scale by touching the up and down yellow arrows on the left side of the yellow bottom panel. Choose between 100 ms, 1 sec and 10 sec using the yellow left and right arrows at the bottom of this yellow panel.

The white lines indicate real time activity in each panel and the red lines indicate peak activity in each panel. Touch the CLEAR button at any time on the top to reset the red peak activity lines.

Each graph has its merits but the biggest value to most users is in capturing both domains' signals and analyzing them together in order to recognize the combined pattern belonging to a specific signal source.



#### MAIN MENU

The MAIN MENU allows access to more of the Yorkie-Pro's settings and information. These include alerts, RF scan persistence, GPS, battery status, country selection and unit information.

#### **VIBRATING ALERT**

Touch the VIBRATING ALERT checkbox to toggle vibrating alerts on or off. When vibrating alerts are turned on, the unit will vibrate every time a set threshold is surpassed.

#### **AUDIBLE ALERT**

Touch the AUDIBLE ALERT checkbox to toggle audible alerts on or off. The unit will beep every time a threshold is surpassed or any button is touched.

#### RF SCAN PERSISTENCE


RF SCAN PERSISTENCE only affects the rate at which Wi-Fi, BT or BLE measurements are displayed. For instance, only the last scan result will be shown when it is set to ALWAYS OFF. The choices include ALWAYS ON, ALWAYS OFF, 10 SECS and 10 MINS. You might need to experiment with these settings depending upon your environment but BVS recommends 10 SECS for most busy RF environments and 10 MINS for less busy RF environments.

#### **BLE TAG SORT**

Touch the BLE Tag Sort checkbox to list only BLE personal trackers on the BLE Measurement Screen. This makes sorting and identification of such devices much easier. Note that when this box is checked on, the BT/BLE TOGGLE button will not appear.

#### **GPS STATUS**


Touch the GPS STATUS button to display the Yorkie-Pro's internal GPS receiver status including latitude, longitude, date, time, fix status, dead reckoning status, 2D fix status, 3D fix status, GNSS + dead reckoning status and time fix status. This information is useful primarily for users performing site security surveys requiring export for reports and later analysis.





#### **BATTERY STATUS**

Touch the BATTERY STATUS button to see estimated remaining runtime down to the minute and instructions for periodically cycling the battery to maintain superior battery life.



#### **SELECT COUNTRY**

Touch the SELECT COUNTRY button to match the country you are in when taking measurements there. These countries only apply to the cellular measurements. The current selected country is indicated by its two letter abbreviation near the top left of the MAIN MEASUREMENT screen. Supported countries or territories include: Unites States (US), Canada (CA), Europe (EU), Australia (AU), New Zealand (NZ), Israel (IL), Sweden (SW), Brazil (BR), Japan (JP), South Korea (KR), Chile (CL), India (IN) and Philippines (PH). Yorkie-Pro ships direct from the factory with support for the country designated by the customer. Check with your BVS sales or support contact for more details about support in your country.



#### **UNIT INFORMATION**

Touch the UNIT INFORMATION button to access this screen for antenna assignments, firmware and your unit's serial number. Be sure to reference these SMA connection assignments when attaching any antennas to your unit. Also be sure to reference this screen for the firmware and serial number for any sales or support related issues.



#### **DATA LOGGING**


Touch the DATA LOGGING button to access this screen. From here, users can sort and review all captured data snaphots or logged data. Begin by choosing between SNAPSHOTS and LOGGING buttons at the top. Data can be sorted by the measurement screen (cellular, BT, BLE, Wi-Fi 2.4 GHz, Wi-Fi 5 GHz and frequency analyzer) used and or by timestamp of measurement. If you have filled your Yorkie-Pro up with data and need more room to store more measurements, choose DELETE SNAPSHOT DATA or DELETE LOGGING DATA button to make more space for data. Be sure you have already connected Yorkie-Pro to a PC running the BVS logging software and have saved the data before you delete any data you might need.

Note: Not all screens support both data logging features. If you do not see the data snaphot (camera icon) or data logging (round record button icon) on top of the measurement screen, you cannot record data.

Approximate Time To Transfer Logged Measurements to PC:

1 Data Snapshot < 100 mSec per snapshot

10 minute Mainscreen Log File
23 seconds
60 minute Mainscreen Log File
2.5 minutes
10 minute WiFi Log File
3.5 seconds
60 minute WiFi Log File
22.4 seconds
10 minute Bluetooth or BLE Log File
3.0 seconds
60 minute Bluetooth or BLE Log File
20.3 seconds



#### Yorkie-Pro Product Safety Info

BVS WIDS (Wireless Intrusion Detection Systems) monitor for cellular, Wi-Fi and BT/BLE signals emitted by standard consumer electronic devices and therefore are rather passive Receivers of RF energy. Most of the time these receivers are passively listening for possible ambient signals of interest. Occasionally, BVS WIDS systems broadcast brief scanning requests. These requests are low energy standard signals just as signals emitted by personal consumer electronic devices, such as cell phones, etc.

#### Wi-Fi

Wi-Fi access points emit electromagnetic radiation in the form of radiofrequency (RF) signals to transmit data wirelessly. The RF signals used by Wi-Fi fall within the non-ionizing part of the electromagnetic spectrum, which means they do not have enough energy to ionize atoms or molecules and, therefore, are generally considered to be non-harmful at typical exposure levels.

The radiofrequency radiation emitted by Wi-Fi devices is classified as non-ionizing radiation, and it is generally considered safe for human exposure within established regulatory limits. Regulatory agencies, such as the Federal Communications Commission (FCC) in the United States, set limits on RF exposure to ensure that devices like Wi-Fi routers operate within safe levels.

#### Bluetooth & Bluetooth Low Energy

Similar to Wi-Fi, Bluetooth technology uses radiofrequency (RF) signals to transmit data wirelessly. Bluetooth operates in the same non-ionizing part of the electromagnetic spectrum as Wi-Fi, and the emitted radiation is generally considered to be safe at typical exposure levels.

Bluetooth devices, such as headphones, speakers, and other peripherals, emit low-power radiofrequency signals. The power levels used in Bluetooth communication are typically much lower than those associated with cell phones and other devices that use higher-powered RF signals.

As with any technology, it's important to follow established guidelines and regulations to ensure safe usage. Regulatory bodies, such as the Federal Communications Commission (FCC) in the United States, set limits on RF exposure to protect against potential health risks. The current scientific consensus is that the RF exposure from Bluetooth devices is not harmful at typical usage levels.

#### Cellphone

The radiofrequency (RF) signals emitted by cell phones are a form of non-ionizing electromagnetic radiation. The consensus among the scientific community, as reflected in the guidelines of various health organizations and regulatory agencies, is that the RF exposure from cell phones, when used within established safety limits, is not likely to cause harm to human health.

Regulatory bodies, such as the Federal Communications Commission (FCC) in the United States, set limits on the Specific Absorption Rate (SAR), which measures the rate at which the human body absorbs RF energy. Cell phones must comply with these SAR limits to ensure that the RF exposure is below levels considered safe.

### Yorkie-Pro PC SOFTWARE

#### Introduction

Yorkie-Pro wireless intrusion detection system (WIDS) is a handheld receiver designed for wireless security audits of data-sensitive government, law enforcement, military and critical infrastructure facilities. Yorkie-Pro detects all nearby wireless PEDs (Personal Electronic Devices) including Cellular, Wi-Fi, Bluetooth and BLE (Bluetooth Low Energy) channels using a high-speed receiver engine in conjunction with a Wi-Fi/BT/BLE demodulator. Yorkie-Pro is also the only device on the market that detects and locates unknown Apple AirTag®, Samsung Galaxy SmartTag® and Tile® Tracker as well any active, hidden GPS trackers used for illegal stalking and tracking.

Yorkie-Pro is also capable of storing screen data such as Snapshot Data and Logged Screen Data.

Snapshot Data is an instance of the data and measurements taken from the current screen and stored in Yorkie-Pro. Yorkie-Pro can store up to 70 snapshots internally.

Logged Screen Data is a continuous collection overtime of current screen data and measurements that is stored onto Yorkie-Pro. Internal storage allows for 5 unique data logging sessions at approximately 13 MB per log file. Depending upon the screen being logged, the resulting data can be logged for a range of time.

Yorkie-Pro PC Software retrieves these types of data from Yorkie-Pro through Mini-USB connection to your Windows machine. Allows you to visualize the data on your PC and save the raw data to an Excel file.

# **Minimum Software Requirements**

Operating System: Windows 8/10/11

RAM: 8 GB

Processor Speed: 2.30 GHz

Hard Drive Space: 5 MB for application installation


Monitor Resolution: 1680 x 1050 (recommended)

.Net Framework: 4.8


Yorkie-Pro Firmware: 2.13

#### Installation

- 1. Make sure your current. Net Framework is 4.8 or higher.
- 2. Open the installation folder and click on setup.exe file.



2. Next, click on the Install.




## **Getting Started**

!Keep the Yorkie-Pro in the **Data Logging** screen during the Data Downloading to improve data transfer. To get there go to the **Main MENU** on the Yorkie-Pro and click on the **DATA LOGGING** 






Connect Yorkie-Pro to the PC using the Mini-USB cable and launch the Yorkie-Pro application. Make sure to select proper COM port.




Once the Yorkie-Pro COM port is selected you will see that Status switched to "Connected" and other information data is filled. Otherwise, if you select the wrong device, you will get an error. Next click the "View" button.




The main window will open up and it will start downloading Snapshot Data.




You can move between different views on the navigation bar on the left.




When all the Snapshots got downloaded you will see a list with populated data. And in the mean time the application will start downloading the Logged Screen Data.



Click on the relative Snapshot to further view the data contents




### Example view of exported Snapshot Data to Excel



When Logged Screen Data has finished downloading, data will be available to view. Each log has multiple records of Entry data.



After selecting View on the relative Log you will be able to see the collected data. Also, you can Export to Excel the whole log or select one or more entries of that log to be exported.



# W24-58-CP-9

M2M / WLAN

D8/05/2015 v A



#### **Dual Band Directional Patch Antenna**

High gain directional antenna

Covers 2.4 & 5GHz for WIFI/WLAN

Ideal WIFI coverage extender for large rooms, car parks & warehouses

The Panorama client patch antenna is a directional wall or mast mounted antenna covering 2.4 & 5GHz for WIFI / WLAN applications.

This antenna is ideal for point to point communications or can be used to cover a wide area thanks to its relatively wide beamwidth in the horizontal and vertical planes. Several of these antennas can be used to provide cost effective sectored coverage.

The antenna is supplied with a 90 degree adjustable wall / mast mount angle bracket to give optimal mounting flexibility.

Ideal to infill network coverage black spots or to provide a consistent connection for subscriber terminals the W24-58-CP-9 is a cost effective solution to network coverage issues.

#### Technical Drawing 93.0 ANTENNA MOUNTING 25.0 BRACKETS ASSY. SUPPLIED LOOSE. Ø4.2 HOLE IN 4 POSNS. 93.0 IDENTITY M4x6LG. PAN HD. POZI - DRIVE ST. STL. SCREW IN 2 POSNS. PLASTIC 6.50 COVER M4 INTERNAL TEETH SMA BULKHEAD SOCKET NICKEL PLATED SHAKE PROOF WASHER IN 2 POSNS. 0 DIECAST 40.0 BOX 36.0





Frogmore, London, SW18 1HF, United Kingdom

PANORAMA ( ANTENNAS

T: +44 (0)20 8877 4444 F: +44 (0)20 8877 4477 E: sales@panorama-antennas.com www.panorama-antennas.com

Waiver: The data given above is indicative of the performance of the product/s under particular conditions and does not imply a guarantee of performance. These specifications are subject to change without notice.





| Part No.               |                |                                   |  |
|------------------------|----------------|-----------------------------------|--|
|                        |                | W24-58-CP-9                       |  |
| Electrical Data        |                |                                   |  |
| Frequency Range (MHz)  |                | 2400-2485 /4900-6000              |  |
| Operational Band       |                | 2.4GHz/5GHz WLAN                  |  |
| VSWR                   |                | ≤ 2:1                             |  |
| Peak Gain: Isotropic   |                | 9dBi                              |  |
| Pattern                |                | Directional                       |  |
| 3dB Beamwidth          | Azimuth Z.4GHz | ŪΩ <sup>a</sup>                   |  |
|                        | Azimuth 5GHz   | 90°                               |  |
| Polarisation           |                | Vertical                          |  |
| Impedance              |                | 50Ω                               |  |
| Max Input Power (W)    |                | 50                                |  |
| Mechanical Data        |                |                                   |  |
| Dimensions (mm)        | Height         | 93 (3.66")                        |  |
|                        | Width          | 93 (3.66")                        |  |
|                        | Depth          | 25 (0.98")                        |  |
| Operating Temp (°C)    |                | -30° / +70°C (-22° / +158°C)      |  |
| Material               |                | Geloy PC/ASA & die cast aluminium |  |
| Colour                 |                | Signal White                      |  |
| Mounting Data          |                |                                   |  |
| Fixing                 |                | Wall mount or Mast mount          |  |
| Environmental Spec     | cification     |                                   |  |
| Wind Load / Resistance |                | 11N at 150km/h                    |  |
| Radome Flammabil       | lity           | UL94 VO - Halogen Free            |  |
| Connector Data         |                |                                   |  |
| Termination            |                | SMA socket                        |  |

# Inbuilding

# WM8-BADEP3G-26-NJ

Low PIM Directional Antenna

24/03/2016: V4





## WM8-BADEP3G-26-NJ

High gain

Mast mount or wall mount

Low PIM & SAR tested to EN50385:2002

Integrate wireless services into one antenna


A versatile high gain directional antenna for in building applications, Panorama's WM8 range allows businesses and facilities to support multiservice/multi-operator wireless coverage. The WM8-BADEP3G-26-NJ supports 2G, 3G, 3G+ and 4G technologies including LTE, AMPS, PCS, GSM, UMTS & AWS with lower gain coverage of WIFI 2.4GHz and LTE 2.6GHz.

The WM8 range is housed in impact resistant, UV light stabilised plastic. The features a heavy duty N female connector making the product ideal for indoor and outdoor deployment, for inbuilding coverage or network infill applications.



This product features Panorama Antennas' PIM Guard Technology and will meet or exceed a third order intermodulation level of < -140dBc.


**Technical Drawing** 



Page 30

# In Building Antennas

## Low PIM Directional Antenna



<sup>\*</sup>Measurements taken looking directly into N connector on antenna housing.



# Low PIM Directional Antenna

|  |   | WME-BADEPEG-ZS-NI   |
|--|---|---|
| Electrical Data                                  |   | 10 3 M 10                                   |
| Ггециелсу Кал                                    |   | 538-350, 1710-2700  |
| Operational Ba                                   |   | LTE700, AMPS 850, CDMA 800, GSM1800, PCS1900, 3G UMTS, AWS, WIFI, LTE 2.6 |
| Peak Gain:<br>Isotropic                          | LTE 700MHz,<br>AMP 3500 & GSM 300         | £.5dBi  |
|  | GSM 1800, PCS1900,<br>3G UM/TS / AWS 2100 | 2여행   |
|  | WIFI 2400, LTE 2500                       | গ্রবন্ধ   |
| A2MM   |   | ~Z.5:1  |
| Polarisation                                     |   | Vertical  |
| Pattern  |   | Directional   |
| Typical Passive intermod. (ZrZŪW, 3rd ord.) d&c" |   | -34⊽  |
| SAR and 'Touch Safe' Test Data                   |   | Acadeding to 50385:2002 (Sands: 850, 900, 1800, 2100, 2600MHz)            |
| Impedance  |   | 55Ω   |
| Max Input Power (W)                              |   | 50  |
| Mechanical Da                                    | ata .                                     |   |
| di-malan.  | Height                                    | 230mm (3.05°)   |
| Dimensions<br>(mm)                               | Width                                     | 180mm (7.08°)   |
| A.n.   | Length                                    | 34mm (3,7")   |
| Operating Temp (°C)                              |   | -30° / +70°C (-2Z° /158°F)  |
| Material   |   | PC/ASA  |
| Colour   |   | White   |
| Connector Dat                                    |   |   |
| Type   |   | N Societ  |
| Mounting Data                                    |   |   |
| Fishing  |   | Pole Mount / Wall Mount   |
| Pole Diameter                                    |   | 20-50 mm (0.8 - 1.95°)  |

<sup>&</sup>quot;Range PIM performance verified under controlled conditions by Anritsu PIM Master test equipment.

Panorama Antennas tid Frogmore, London, SW18 1HF, United Kingdom

7: +44 (0)20 8877 4444 F: +44 (0)20 8877 4477

E: sales@panorama-antennas.com www.panorama-antennas.com

Waiver. The data given above is indicative of the performance of the product/s under particular conditions and does not imply a guarantee of performance or a warranty of fitness for any particular purpose. These specifications are subject to change without notice.

Copyright © Panorama Antennas Ltd. All rights reserved.



# SPECIFICATION PATENTED

Part No. : TG.30.8113

Product Name : Apex Hinged TG.30

Ultra-Wideband 4G LTE Antenna

Feature : LTE / GSM / CDMA /DCS /PCS / WCDMA / UMTS /

HSDPA / GPRS / EDGE /GPS /Wi-Fi 698MHz to 960MHz, 1575.42MHz

1710MHz to 2700Mhz

Typical 70%+ Efficiency and 3dBi+ Peak Gain

Dipole Swivel Terminal Antenna

Hinged 90° termination with SMA(M) Connector

RoHS Compliant



Page 33



## 2. Specification

| ELECTRICAL                    |         |         |         |             |             |             |           |
|-------------------------------|---------|---------|---------|-------------|-------------|-------------|-----------|
| Frequency (MHz)               | 700~800 | 824~960 | 1575.42 | 1710 ~ 1880 | 1850 ~ 1990 | 1710 ~ 2170 | 2400~2800 |
|                               |         |         | Peak    | Gain (dBi)  |             |             |           |
| Free Space                    |         |         |         |             |             |             |           |
| Straight                      | 1.1     | 0.3     | 1.1     | 1.9         | 2,7         | 2.6         | 2.7       |
| Free Space Bent               | 2.6     | 1.5     | 2.9     | 2.7         | 3.1         | 3.1         | 2.0       |
| 30x30cm GP<br>center Straight | 2:1     | 0.7     | 2.9     | 1,5         | 1.9         | 2.0         | 2.9       |
| 30x30cm GP<br>center Bent     | 3.5     | 1.7     | 5.2     | 5,9         | 6.7         | 6.4         | 4.9       |
| 30x30cm GP edge<br>Straight   | 2.6     | 1.3     | 1.7     | 2.1         | 2.1         | 2.3         | 4.3       |
| 30x30cm GP edge<br>Bent       | 2.6     | 1.8     | 3.1     | 2.1         | 3.0         | 2.8         | 5.1       |
| PCB edge Straight             | 1.4     | 1.2     | 0.9     | 2.5         | 3.2         | 3.0         | 1.4       |
| PCB edge Bent                 | 2.1     | 0.1     | 2.1     | 2,4         | 3.6         | 3.4         | 3.0       |
| Average Gain (dB)             |         |         |         |             |             |             |           |
| Free Space<br>Straight        | -1.1    | -2.2    | -2.0    | -1.5        | -1.2        | -1.3        | -3.5      |
| Free Space Bent               | -1.1    | -2.3    | -1.5    | -1.5        | -1.1        | -1.2        | -3.1      |
| 30x30cm GP<br>center Straight | -0.6    | -1.6    | -2.0    | -1.8        | -1.7        | -1.7        | -3.8      |
| 30x30cm GP<br>center Bent     | -3.5    | -4.9    | -2.8    | -2.4        | -1,8        | -2.0        | -3.0      |
| 30x30cm GP edge<br>Straight   | -0.6    | -1.5    | -1.9    | -1.6        | -1.4        | -1.4        | -3.1      |
| 30x30cm GP edge<br>Bent       | -0.6    | -1.7    | -1.6    | -1,5        | -1.2        | -1.3        | -3.1      |
| PCB edge Straight             | -1.0    | -2.0    | -2.0    | -1.6        | -1,4        | -1.4        | -3.5      |
| PCB edge Bent                 | -0.8    | -2.5    | -1.6    | -1.5        | -1.1        | -1.3        | -3,0      |



|                        |                  |         | ELE                        | CTRICAL     |                |             |           |
|------------------------|------------------|---------|----------------------------|-------------|----------------|-------------|-----------|
| Frequency (MHz)        | 700~800          | 824~960 | 1575.42                    | 1710 ~ 1880 | 1850 ~ 1990    | 1710 ~ 2170 | 2400~2800 |
|                        |                  |         | Effic                      | iency (%)   |                |             |           |
| Free Space Straight    | 79               | 61      | 63                         | 71          | 76             | 75          | 45        |
| Free Space Bent        | 78               | 60      | 70                         | 72          | 78             | 75          | 49        |
| 30x30cm GP center      | 100              | 172     |                            |             |                | 100         |           |
| Straight               | 86               | 69      | 62                         | 66          | 67             | 68          | 42        |
| 30x30cm GP center      |                  |         |                            |             |                |             |           |
| Bent                   | 47               | 32      | 51                         | 58          | 66             | 64          | 51        |
| 30x30cm GP edge        |                  |         |                            |             |                |             |           |
| Straight               | 88               | 70      | 65                         | 69          | 72             | 72          | 49        |
| 30x30cm GP edge        |                  |         |                            |             |                |             |           |
| Bent                   | 88               | 67      | 69                         | 70          | 76             | 74          | 49        |
| PCB edge Straight      | 80               | 63      | 63                         | 69          | 73             | 73          | 45        |
| PCB edge Bent          | 83               | 57      | 70                         | 71          | 77             | 75          | 50        |
| Impedance              |                  |         |                            | 500         | 2              |             |           |
| Polarization           |                  | Linear  |                            |             |                |             |           |
| Radiation Pattern Omni |                  |         |                            |             |                |             |           |
| Input Power            | Input Power 10 W |         |                            |             |                |             |           |
|                        |                  |         | MEC                        | HANICAL     |                |             |           |
| Casing                 |                  |         |                            | UV Re       | sistant PC/ABS |             |           |
| Connecto               | r                |         |                            | SMA M       | ale Hinged 90° | ST -        |           |
|                        |                  |         | ENVIR                      | ONMENTAL    |                |             |           |
| Temperature F          | Range            |         |                            | -40         | 0°C to 85°C    |             |           |
| Humidity               |                  |         | Non-condensing 65°C 95% RH |             |                |             |           |




| LTE BANDS   |                      |                               |         |  |  |
|---|----------------------|-------------------------------|---------|--|--|
| Band Number LTE / LTE-Advanced / WCDMA / HSPA / HSPA+ / |                      |                               |         |  |  |
|   | Uplink               | Downlink                      | Covered |  |  |
| 1   | UL: 1920 to 1980     | DL; 2110 to 2170              | 1       |  |  |
| 2   | UL: 1850 to 1910     | DL: 1930 to 1990              | 1       |  |  |
| 3   | UL: 1710 to 1785     | DL: 1805 to 1880              | 1       |  |  |
| 4   | UL: 1710 to 1755     | DL: 2110 to 2155              | 1       |  |  |
| 5   | UL: 824 to 849       | DL: 869 to 894                | 1       |  |  |
| 7   | UL: 2500 to 2570     | DL:2620 to 2690               | 1       |  |  |
| В   | UL: 880 to 915       | DL: 925 to 960                | 1       |  |  |
| 9   | UL: 1749.9 to 1784.9 | DL: 1844.9 to 1879.9          | 1       |  |  |
| 11  | UL: 1427.9 to 1447.9 | DL: 1475.9 to 1495.9          | ×       |  |  |
| 12  | UL; 699 to 716       | DL: 729 to 746                | 1       |  |  |
| 13  | UL: 777 to 787       | DL: 746 to 756                | 1       |  |  |
| 14  | UL: 788 to 798       | DL: 758 to 768                | 1       |  |  |
| 17  | UL: 704 to 716       | DL: 734 to 746 (LTE only)     | 1       |  |  |
| 18  | UL: 815 to 830       | DL: 860 to 875 (LET only)     | 1       |  |  |
| 19  | UL: 830 to 845       | DL: 875 to 890                | 1       |  |  |
| 20  | UL: 832 to 862       | DL: 791 to 821                | 1       |  |  |
| 21  | UL: 1447.9 to 1462.9 | DL: 1495.9 to 1510.9          | lk.     |  |  |
| 22  | UL: 3410 to 3490     | DL: 3510 to 3590              | le.     |  |  |
| 23  | UL:2000 to 2020      | DL; 2180 to 2200 (LTE only)   | 1       |  |  |
| 24  | UL:1625.5 to 1660.5  | DL: 1525 to 1559 (LTE only)   | 1       |  |  |
| 25  | UL: 1850 to 1915     | DL: 1930 to 1995              | 1       |  |  |
| 26  | UL: 814 to 849       | DL: 859 to 894                | 1       |  |  |
| 27  | UL: 807 to 824       | DL: 852 to 869 (LTE only)     | 1       |  |  |
| 28  | UL: 703 to 748       | DL: 758 to 803 (LTE only)     | 1       |  |  |
| 29  | UL: =                | DL: 717 to 728 (LTE only)     | 1       |  |  |
| 30  | UL: 2305 to 2315     | DL: 2350 to 2360 (LTE only)   | 1       |  |  |
| 31  | UL: 452.5 to 457.5   | DL; 462,5 to 467,5 (LTE only) | k       |  |  |
| 32  | UL: -                | DL: 1452 - 1496               | ×       |  |  |
| 35  | 1850                 | ) to 1910                     | 1       |  |  |
| 38  | 2570                 | ) to 2620                     | 1       |  |  |
| 39  |                      | ) to 1920                     | 1       |  |  |
| 40  | 2300                 | ) to 2400                     | 1       |  |  |
| 41  | 2496                 | i to 2690                     | 1       |  |  |
| 42  | 3400                 | ) to 3600                     | J.      |  |  |
| 43  | 3600                 | ) to 3800                     | 3C      |  |  |




## 3. Antenna Characteristics

#### 3.1 Return Loss



## 3.2 Peak Gain



Page 37

#### ANT-DB1-LCD-ccc

## **Data Sheet**



#### **Product Description**

The Linx LCD Dipole Antenna is a superior solution for users searching for best-in-class performance for WLAN devices using Dual-Band WiFi (802.11ac, 802.11n, 802.11ax) or U-NII applications.

With a compact package and low price, the LCD's high peak gain and superior efficiency make it an excellent option for high volume, cost sensitive applications.

Dipole design means that no additional ground plane is required.

#### Features

- Excellent performance
- Dual-band
- Very low VSWR
- Omni-directional pattern
- Tilt and swivel base
- Standard SMA or Part 15 compliant RP-SMA connector



#### Ordering Information


ANT-DB1-LCD-RPS (with RP-SMA connector)
ANT-DB1-LCD-SMA (with SMA connector)

| Parameter                   |  |                  |                           |
|-----------------------------|--|------------------|---------------------------|
| Recommended Frequency       | 2.4GHz WIFI                                    | U-NII            | 5.8GHz WIFI7 U-NII-3 Band |
| Range                       | 2.4 - 2.5GHz                                   | 5.125 - 5.725GHz | 5.725 - 5.875GHz          |
| VSWR                        | <2:1   | <2:1             | <2:1                      |
| Peak Gain (max in the band) | 2 8dBi   | 4.5dBi           | 2.92dBi                   |
| Average Gain (typical)      | -0.6dBi  | -1.5dBi          | -2.2dBi                   |
| Efficiency (typical)        | 85%  | 70%              | 65%                       |
| Polarization                |  | Linear           |                           |
| Radiation                   | Omni-Directional                               |                  |                           |
| Max Power                   | 10W  |                  |                           |
| Wavelength                  | 1/2-wave                                       |                  |                           |
| Impedance                   | 50-ohms  |                  |                           |
| Connection                  | SMA Plug (Male) or RPS (Reverse Polarity Male) |                  |                           |
| Weight                      | 7.4g (0.26oz.)                                 |                  |                           |
| Operating Temperature Range | -40°C to +80°C                                 |                  |                           |


## Gain Plots - Edge of Plane, Bent 90°



### 2400 - 2500MHz



## 5720 - 5880MHz



- 1) Make sure the connection is hand-tight with the SMA connector at the end connecting to the unit before giving it a quarter turn with a hall wrench to make sure it is properly secured.
- 2) It is very important that you DO NOT kink the RF cable going to the GPS antenna. If it gets bent hard or is dented from being caught in the window or door frame too firmly, cable shielding performance will quickly degrade.
- The GPS antenna should be placed at least 1.5 feet (1/2 a meter) away from any other receiver or transmit antennas. For example, if you put the 4 mag mount antennas on the roof of the vehicle than make sure they are at least 1.5 feet away from each other and the GPS mag mount antenna. If there is no sufficient spacing, you should locate the GPS antenna on the rear trunk lid for example.

NMEA recommends three feet of separation between GPS antennas and most other antennas including VHF, cellular and Wi-Fi antennas. This is typically not the case and there are many combo antennas on the market that combine GPS with other antennas in a single enclosure. But if you have GPS reception issues, try testing a few locations before choosing the final location to be sure the GPS is not impacted by other antennas.

4) Be sure there is a <u>clear path to the sky</u> from your GPS antenna. Unlike other antennas that are looking for wireless signals from anywhere, GPS antennas must have a clear path to the sky to receive signals from GPS satellites. If there is a lot of metal clutter directly above the location of the GPS antenna, it is unlikely you will get a good GPS signal.

The ideal place to mount a GPS antenna is out in the open, allowing radio signals from orbiting satellites to reach the antenna uninterrupted. This way, your antenna will be directly facing the sky with no obstructions whatsoever. If you're mounting your antenna to a car, place the antenna in the middle of the car's roof.

#### **ANT-GPS-SH2-ccc**

## **Data Sheet**



#### **Product Description**

Covering both GPS and GLONASS frequencies, The high-performance SH2 Series GPS antennas combine superior performance and low power consumption. They are designed to survive the weather with an IP66 rating and UV stabilized plastic and cable. This makes them ideal for telematics, fleet management, navigation, tracking and other applications that require a compact, high-performance GPS antenna. For maximum compatibility with the host receiver, the SH2 accepts supply voltages from 2.5 to 5.5VDC and is protected against shorts, over current, or reverse polarity situations. The antennas attach via a SMA, MCX, MMCX or customer-specified connector.

#### **Features**

- Compact
- High-gain, low-noise design
- Low current consumption
- Protection circuit
- UV protection
- IP66 rating
- Rugged & damage-resistant
- Magnetic mount

#### **Electrical Specifications**

Center Frequency: 1575.42MHz, 1602MHz Bandwidth: 10MHz @ -3dB point

VSWR: 1.5 typ.

Antenna Peak Gain: 5.0dB typ.

Impedance: 50-ohms

Axial Ratio: 1.0dB typ.

Elev. Angle Cov.: 5–90 degrees

Az. Bearing Cov.: 360 degrees

Polarization: RHCP

System Gain: 28±1dB typ. (includes 3m


cable & filter loss)

Noise Figure: 1.0dB typ.

Input Voltage: +2.5 to +5.5VDC

Current: 5–8mA typ. @ 5V

Mounting: Magnetic and/or screw



Cable: 117" +/-6" (3m) RG-174U

(Low-loss, 0.7dB/m)

Connection: SMA, MCX, MMCX <sup>1</sup>

Weight: 2.79oz (79g)
Plastic UV Resistance: UL-746C f1
Cable UV Resistance: UL-758
Ingress Protection: IP66

Oper. Temp. Range: -40°C to +85°C <sup>2</sup>

#### Ordering Information


ANT-GPS-SH2-SMA (with SMA connector)
ANT-GPS-SH2-MCX (with MCX connector)
ANT-GPS-SH2-MMX (with MMCX connector)

-1- Revised 4/11/2018

<sup>&</sup>lt;sup>1</sup> Contact Linx for custom cable lengths and connectors.

<sup>&</sup>lt;sup>2</sup> Operation below –30°C may result in a slightly longer time to first fix.

#### **VSWR Graph**



#### What is VSWR?

The Voltage Standing Wave Ratio (VSWR) is a measurement of how well an antenna is matched to a source impedance, typically 50-ohms. It is calculated by measuring the voltage wave that is headed toward the load versus the voltage wave that is reflected back from the load. A perfect match has a VSWR of 1:1. The higher the first number, the worse the match, and the more inefficient the system. Since a perfect match cannot ever be obtained, some benchmark for performance needs to be set. In the case of antenna VSWR, this is usually 2:1. At this point, 88.9% of the energy sent to the antenna by the transmitter is radiated into free space and 11.1% is either reflected back into the source or lost as heat on the structure of the antenna. In the other direction, 88.9% of the energy recovered by the antenna is transferred into the receiver. As a side note, since the ":1" is always implied, many data sheets will remove it and just display the first number.

.....


#### How to Read a VSWR Graph

VSWR is usually displayed graphically versus frequency. The lowest point on the graph is the antenna's operational center frequency. In most cases, this is different than the designed center frequency due to fabrication tolerances. The VSWR at that point denotes how close to 50-ohms the antenna gets. Linx specifies the recommended bandwidth as the range where the typical antenna VSWR is less than 2:1.



#### **Gain Plots**






#### **About Gain Plots**

The true measure of the effectiveness of an antenna in any given application is determined by the gain and radiation pattern measurement. For antennas gain is typically measured relative to a perfect (isotropic) radiator having the same source power as the antenna under test, the units of gain in this case will be decibels isotropic (dBi). The radiation pattern is a graphical representation of signal strength measured at fixed distance from the antenna.

Gain when applied to antennas is a measure of how the antenna radiates and focuses energy into free space. Much like a flashlight focuses light from a bulb in a specific direction, antennas focus RF energy into specific directions. Gain in this sense refers to an increase in energy in one direction over others.

It should also be understood that gain is not "free", gain above 0dBi in one direction means that there must be less gain in another direction. Pictorially this can be pictured as shown in the figures to the right. The orange pattern represents the radiation pattern for a perfect dipole antenna, which is shaped like a donut. The pattern for an omnidirectional antenna with gain is shown in blue. The gain antenna is able to work with a device located further from the center along the axis of the pattern, but not with devices closer to the center when they are off the axis – the donut has been squished.



Gain is also related to the overall physical size of the antenna, as well as surrounding materials. As the geometry of the antenna is reduced below the effective wavelength (considered an electrically small antenna) the gain decreases. Also, the relative distance between an electrically small antenna and its associated ground impacts antenna gain.

Copyright © 2018 Linx Technologies

159 Ort Lane, Merlin, OR 97532 Phone: +1 541 471 6256 Fax: +1 541 471 6251 www.linxtechnologies.com





## AA Portable Power Corp www.batteryspace.com, Email: Sales@batteryspace.com

#### Safety Data Sheets (SDSs)

**Section 1 - Identification** 

Product Name: Lithium Ion/Lithium Polymer Battery (LiCoO2). Please refer part number and watt-hours on your purchase record.

Manufacturer / Distributor Name: AA Portable Power Corp

Address: 825 S 19th Street, Richmond, CA 94804, Tel: 510-525-2328 Fax: 510-439-2808

Email: sales@batteryspace.com

Emergency Tel (Within USA and Canada): Here should be your company's emergency telephone number.

Emergency Tel (Outside USA and Canada) for Shipment to USA: Here should be your company's emergency telephone number.

Recommended Use: General use

Restrictions on Use: N/A

#### Section 2 - Hazard(s) Identification

Routes of Entry: Inhalation, Skin, Ingestion.

#### Health Hazards (Acute and Chronic)

These chemicals are contained in a sealed can. Risk of exposure occurs only if the battery is mechanically or electrically abused. The most likely risk is acute exposure when a battery vents.

#### Sign/Symptoms of Exposure

A shorted lithium battery can cause thermal and chemical burns upon contact with the skin. May be a reproductive hazard.

#### Medical Conditions Generally Aggravated by Exposure

An acute exposure will not generally aggravate any medical condition.

Required Label Elements: N/A

Section 3 - Composition/Information on Ingredients

| Ingredient                  | Content                   | CAS Index No. | EINECS    |
|-----------------------------|---------------------------|---------------|-----------|
|                             | (percent of total weight) |               |           |
| LithiumCobalt Oxide(LiCoO2) | 50%                       | 12190-79-3    | 235-362-0 |
| Carbon(Graphite)            | 10%                       | 7782-42-5     | 231-955-3 |
| PP                          | 5                         | 9003-07-0     | N/A       |
| PVDF                        | 2                         | 24937-79-9    | N/A       |
| PE                          | 5                         | 9002-88-4     | N/A       |
| CMC                         | 0.5                       | 9004-32-4     | N/A       |
| LiPF6                       | 5                         | 21324-40-3    | 244-334-7 |
| EC                          | 5                         | 96-49-1       | 202-510-0 |
| DMC                         | 5                         | 616-38-6      | 210-478-4 |
| Ni                          | 2.5                       | 7440-02-0     | 231-111-4 |
| Cu                          | 5                         | 7440-50-8     | 231-159-6 |
| Al                          | 5                         | 7429-90-5     | 231-072-3 |

Trade Secret Claims: N/A

#### Section 4 – First-aid Measures

Eye: Flush eyes with plenty of water for at least 15 minutes, occasionally lifting the upper and lower eyelids. Get medical aid.

Skin: Remove contaminated clothes and rinse skin with plenty of water or shower for 15 minutes. Get medical aid.



## AA Portable Power Corp www.batteryspace.com, Email: Sales@batteryspace.com

Inhalation: Remove from exposure and move to fresh air immediately. Use oxygen if available.

Ingestion: Give at least 2 glasses of milk or water. Induce vomiting unless patient is unconscious. Call a physician.

#### Section 5 – Fire-fighting Measures

Flash Point: N/A.

Auto-Ignition Temperature: N/A.

Extinguishing Media: Use only Lith-X (Class D extinguishing media) on fire involving lithium batteries or raw lithium metal. Do not use

for this purpose water, sand, CO2, Halon, dry powder or soda ash extinguishers.

Special Fire-Fighting Procedures: Self-contained breathing apparatus.

Unusual Fire and Explosion Hazards: Cell may vent when subjected to excessive heat-exposing battery contents.

Hazardous Combustion Products: Carbon monoxide, carbon dioxide, lithium oxide fumes

Firefighting: In case of fire in an adjacent area, use Lith-X (Class D extinguishing media). Do not use water.

#### Special protective equipment for firefighters:

Respiratory protection: Respiratory equipment of a gas cylinder style or protection-against-dust mask

Hand protection: Protective gloves

• Eye protection: Goggle or protective glasses designed to protect against liquid splashes

Skin and body protection: Protective cloth

#### Section 6 - Accidental Release Measures

#### Steps to be taken in case Material is Released or Spilled

If the battery is accidentally broken and organic electrolyte leaks out, wipe it up with a cloth, and dispose of it in a plastic bag and put into a steel can. The preferred response is to leave the area and allow the batteries to cool and vapors to dissipate. Provide maximum ventilation. Avoid skin and eye contact or inhalation of vapors. Remove spilled liquid with absorbent and incinerate.

#### Waste Disposal Method

It is recommended to discharge the battery to the end, handing in the abandoned batteries to related department unified, dispose of the batteries in accordance with approved local, state, and federal requirements. Consult state environmental protection agency and/or federal EPA.

#### Section 7 - Handling and Storage

The batteries should not be opened, destroyed or incinerate, since they may leak or rupture and release to the environment the ingredients that they contain in the hermetically sealed container. Do not short circuit terminals, or over charge the battery, forced over-discharge, throw to fire. Do not crush or puncture the battery, or immerse in liquids.

#### Precautions to be taken in handling and storing

Avoid mechanical or electrical abuse. Storage preferably in cool dry and ventilated area which is subject to little temperature change. Storage at high temperatures should be avoided. Do not place the battery near heating equipment, nor expose to direct sunlight for long periods.

#### Other Precautions

Batteries may explode or cause burns, if disassembled, crushed or exposed to fire or high temperatures. Do not short or install with incorrect polarity.

#### **Section 8 - Exposure Controls / Personal Protection**

**Respiratory Protection:** In case of battery venting, provide as much ventilation as possible. Avoid confined areas with venting batteries. Respiratory Protection is not necessary under conditions of normal use.

Ventilation: Not necessary under conditions of normal use.



## AA Portable Power Corp www.batteryspace.com, Email: Sales@batteryspace.com

Protective Gloves: Not necessary under conditions of normal use.

Other Protective Clothing or Equipment: Not necessary under conditions of normal use.

**Personal Protection is recommended for venting batteries:** Respiratory Protection, Protective Gloves, Protective Clothing and safety glass with side shields.

OSHA's Permissible Exposure Limits (PELs): N/A

Threshold Limit Values (TLVs): N/A

#### Section 9 - Physical and Chemical Properties

**Appearance Characters:** 

Physical state: Solid,

Form: Cylindrical or Prismatic or Pouch,

Color: Depends on the PVC wrapper, can be green/white/black/yellow

Odor: Odorless

#### Section 10 - Stability and Reactivity

Stability: Stable under normal use

Conditions to Avoid: External short-circuit, crushes, deformation, high temperature, mechanical abuse and electrical abuse, direct sunlight

and high humidity.

Hazardous Decomposition Products: N/A.

Hazardous Polymerization: N/A.

If leaked, forbidden to contact with strong oxidizers, mineral acids, strong alkalies, halogenated hydrocarbons.

#### **Section 11 - Toxicological Information**

Inhalation, skin contact and eye contact are possible when the battery is opened. Exposure to internal contents, the corrosive fumes will be very irritating to skin, eyes and mucous membranes. Overexposure can cause symptoms of non-fibrotic lung injury and membrane irritation.

Numerical Measures of Toxicity: No toxicity.

#### **Section 12 - Ecological Information**

When promptly used or disposed the battery does not present environmental hazard. When disposed, keep away from water, rain and snow.

#### **Section 13 - Disposal Considerations**

#### APPROPRIATE METHOD OF DISPOSAL OF SUBSTANCE OR PREPARATION

If batteries are still fully charged or only partially discharged, they can be considered a reactive hazardous waste because of significant amount of unreacted or unconsumed lithium remaining in the spent battery. The batteries must be neutralized through an approved secondary treatment facility prior to disposal as a hazardous waste. Recycling of battery can be done in authorized facility, through licensed waste carrier.

#### **Section 14 - Transport Information**

UN Number: 3480 (3481 when the battery is contained in equipment or packed with equipment)

Proper shipping name: Lithium ion batteries ("lithium ion batteries contained in equipment" or "lithium ion batteries packed with

#### **Ground Transportation:**

Equipment")

| ≤20Wh/cell or ≤100Wh/battery  | non-regulated  |
|---|--|
| 20Wh <cell≤60wh 100wh<battery≤300wh<="" or="" th=""><th>non-regulated, label: "LITHIUM BATTERIES—FORBIDDEN FOR</th></cell≤60wh> | non-regulated, label: "LITHIUM BATTERIES—FORBIDDEN FOR |



#### AA Portable Power Corp www.batteryspace.com, Email: Sales@batteryspace.com

|   |                               | TRANSPORT ABOARD AIRCRAFT AND VESSEL." |
|---|-------------------------------|--|
| V | >60Wh/cell or > 300Wh/battery | Regulated as Class 9                   |
|   | Non UN38.3 Tested             | Ship per 49 CFR 173.185(e)             |

#### Air Transportation: ICAO/IATA-DGR, only UN38.3 tested batteries can be ship by Air. Regulated as Class 9, Cargo Only

| Ī |              | Non UN38.3 Tested              | Can not ship by Air              |
|---|--------------|--------------------------------|----------------------------------|
| Ī | $\checkmark$ | UN38.3 Tested Cell and battery | Regulated as Class 9, Cargo Only |

| Standalone   | Lithium Ion Standalone (P.I. 965) UN 3480   |
|--------------|---|
| Packed With  | Lithium Ion Packed With (P.I. 966) UN 3481  |
| Contained in | Lithium Ion Contained in (P.I. 967) UN 3481 |

Ocean Transportation: IMO-IMDG, only UN38.3 tested batteries can be ship by Ocean. Regulated as Class 9

Separate Li-ion batteries when shipping to prevent short-circuiting. They should be packed in strong packaging for support during transport. In the case of transportation, confirm no leakage and no overspill from a container. Take in a cargo of them without falling, dropping and breakage. Prevent collapse of cargo piles and wet by rain. The container must be handled carefully. Do not give shocks that result in a mark of hitting on a cell. Please refer to Section 7-HANDLING AND STORAGE also.

#### **Section 15 - Regulatory Information**

#### Law Information

《Dangerous Goods Regulation》

《Recommendations on the Transport of Dangerous Goods Model Regulations》

《Classification and code of dangerous goods》

《Occupational Safety and Health Act》 (OSHA)

《California Proposition 65》

《Resource Conservation and Recovery Ac》 (RCRA)

《Toxic Substances Control Act》 (TSCA)

《Superfund Amendments and Reauthorization Act Title III (302/311/312/313)》 SARA

《Code of Federal Regulations》 (49CFR 173.185)

 $\langle\!\langle International\ Maritime\ Dangerous\ Goods \rangle\!\rangle$ 

IATA Lithium Battery Guidance

In accordance with all Federal, State and Local laws.

#### **Section 16 - Other Information**

The above information is based on the data of which we are aware and is believed to be correct as of the data hereof. Since this information may be applied under conditions beyond our control and with which may be unfamiliar and since data made available subsequent to the data hereof may suggest modifications of the information, we do not assume any responsibility for the results of its use. This information is furnished upon condition that the person receiving it shall make his own determination of the suitability of the material for his particular purpose.

SDSs Creation Date: January 22, 2010 SDSs Revision Date: February 8, 2021