



WIRELESS GAMING KEYBOARD ROG FALCHION

Quick Start Guide

快速使用指南 (繁體中文)

快速使用指南 (简体中文)

クイックスタートガイド

빠른 시작 설명서

Guide de démarrage rapide

Schnellstartanleitung

Guida rapida

Краткое руководство

Guía de inicio rápido

Beknopte handleiding

Hızlı Başlangıç Kılavuzu

Beüzemelési útmutató

Стисле керівництво для початку експлуатації

Instrukcja szybkiej instalacji

Rychlý průvodce

Ghid de pornire rapidă

Snabbstartsguide

Stručný návod na spuštění

Quick Start-vejledning


Pikaopas

Hurtigstartvejledning

Guia de consulta rápida

دليل التشغيل السريع

Package Contents



ROG Falchion wireless gaming keyboard (US layout)* /
ROG Falchion 無線電競鍵盤 (美式布局)* /
ROG Falchion 无线电竞键盘 (美式布局)*



Keyboard cover / 鍵盤蓋 / 键盘盖



Technical documents / 技術文件 / 技术文件



USB Type-C cable / USB Type-C* 傳輸線 /
USB Type-C* 数据线



Wireless dongle extender* /
無線接收器延長器* /
无线接收器延长器*



USB Wireless Dongle /
USB 無線接收器 /
USB 无线接收器



Sticker / 貼紙 / 贴纸

* The illustration is for reference only. Actual product specifications may vary with models, such as keyboard layout. /
圖示僅供參考。實際產品規格如鍵盤佈局可能因型號而異。 /
圖示仅供参考。实际产品规格如键盘布局可能因型号而异。


** Only use the wireless dongle extender for the wireless dongle. /
無接收器延長器僅可用於連接無線接收器。 /
无线接收器延长器仅可用于连接无线接收器。

Q17044
First Edition
August 2020
Copyright © ASUS/TEK Computer Inc.
All Rights Reserved




Keyboard features


Top view (US layout for reference)



Rear view



Left view



1 Win lock indicator / Win lock 指示燈 / Win lock 指示灯

2 RGB indicator / RGB 指示燈 / RGB 指示灯

3 Caps Lock indicator / 大寫字母鎖定指示燈 / 大写字母锁定指示灯

4 Kickstand / 支架 / 支架

5 Power switch / 電源開關 / 电源开关

6 USB Type-C* port / USB Type-C* 連接埠 / USB Type-C* 接口

7 Magnetic dongle storage / 無線接收器磁吸收納 / 无线接收器磁吸收纳

8 Up button / 向上按鍵 / 向上按键

9 Slider bar / 滑動條 / 滑动条

10 Down button / 向下按鍵 / 向下按键

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

Getting started

1. Connect the bundled Type-C cable to your keyboard.
2. Connect your keyboard to the PC.
3. Download and install the Armoury Crate software from https://www.asus.com/supportonly/Armoury%20Crate/HelpDesk_Download/
4. Follow the software instructions to update your keyboard's firmware.
5. Customize your keyboard using Armoury Crate.

開始使用

1. 取下鍵盤上的無線接收器。
2. 將無線接收器連接到電腦的 USB 連接埠。
3. 請至 https://www.asus.com/tw/supportonly/Armoury%20Crate/HelpDesk_Download/ 下載並安裝 Armoury Crate 軟體。
4. 依照軟體指示更新鍵盤韌體。
5. 透過 Armoury Crate 客製化您的鍵盤。

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

Setting up as a wireless keyboard

1. Remove the wireless dongle from the keyboard.
2. Insert the wireless dongle to a USB port on the PC.
3. Set the power switch to **ON**.

Battery Status

The RGB indicator on your gaming keyboard will turn **red (breathing)** and the LEDs for all the other keys will switch off when the battery power is below 20% in wireless mode. You may charge your gaming keyboard by using the bundled USB cable.

開始使用

1. 取下鍵盤上的無線接收器。
2. 將無線接收器連接到電腦的 USB 連接埠。
3. 請至 https://www.asus.com/tw/supportonly/Armoury%20Crate/HelpDesk_Download/ 下載並安裝 Armoury Crate 軟體。
4. 依照軟體指示更新鍵盤韌體。
5. 透過 Armoury Crate 客製化您的鍵盤。

設定為無線鍵盤

1. 取下鍵盤上的無線接收器。
2. 將無線接收器連接到電腦的 USB 連接埠。
3. 將電源開關撥至開啟 (ON) 位置。

電池狀態

在無線模式下，當電池電量低於 20% 時，電競鍵盤上的 RGB 指示燈會亮紅色（呼吸），且其他所有按鍵的燈效都熄滅。您可以使用隨附的 USB 線為

Key combinations

Hot Key	Function
	Play/Pause
	Stop
	Previous track
	Next track
	Mute
	Volume down
	Volume up

Hot Key	Function
	Scroll Lock
	Menu
	Print screen
	End
	Home
	Backtick (~)
	Tilde (~)

Function name	Hot Key	On	Off
Slider bar lock		+ Slider bar (TAB key will light up white when On)	Use Slider bar directly (default)
			Windows key will be locked (Win lock indicator will light up when On)
Fn lock		Swap all function keys (1, 2, 3... =) to F1-F12 (Its key will light up white when On)	Function keys (1, 2, 3... =) remain the same

Ukraine Certification Logo



Function	Frequency	Maximum Output Power (EIRP)
2.4GHz wireless	(2403 - 2480MHz) - Mouse	dBm
	(2403 - 2480 MHz) - Dongle	dBm

CE Mark Warning



English
ASUSTeK Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of related Directives. Full text of EU declaration of conformity is available at: www.asus.com/support

Français
ASUSTeK Computer Inc. déclare par la présente que cet appareil est conforme aux critères essentiels et autres clauses pertinentes des directives concernées. La déclaration de conformité de l'UE peut être téléchargée à partir du site Internet suivant : www.asus.com/support

Deutsch
ASUSTeK Computer Inc. erklärt hiermit, dass dieses Gerät mit den wesentlichen Anforderungen und anderen relevanten Bestimmungen der zugehörigen Richtlinien übereinstimmt. Der gesamte Text der EU-Konformitätserklärung ist verfügbar unter: www.asus.com/support

Italiano
ASUSTeK Computer Inc. con la presente dichiara che questo dispositivo è conforme ai requisiti essenziali e alle altre disposizioni pertinenti con le direttive correlate. Il testo completo della dichiarazione di conformità UE è disponibile all'indirizzo: www.asus.com/support

Русский
Компания ASUS заявляет, что это устройство соответствует основным требованиям и другим соответствующим условиям соответствующих директив. Подробную информацию, пожалуйста, смотрите на www.asus.com/support

Български
Съставното ASUS/TEK Computer Inc. декларира, че това устройство е в съответствие със съществени изисквания и другите приложими постановления на свързаните директиви. Пълният текст на декларацията за съответствие на ЕС е достъпен на адрес: www.asus.com/support

Hrvatski
ASUSTeK Computer Inc. ovim izjavljuje da je ovaj uređaj uskladan s bitnim zahtjevima i ostalim odgovarajućim odredbama vezanim direktiva. Cijeli tekst EU izjave o sukladnosti dostupan je na: www.asus.com/support

Čeština
Společnost ASUSTEK Computer Inc. tímto prohlašuje, že toto zařízení splňuje základní požadavky a další příslušná ustanovení souvisejících směrnic. Plně znění prohlášení o shodě EU je k dispozici na adrese: www.asus.com/support

Dansk
ASUSTeK Computer Inc. erklærer hermed, at denne enhed er i overensstemmelse med hovedkravene og andre relevante bestemmelser i de relaterede direktiver. Høle EU-overensstemmelseserklæringen kan findes på: www.asus.com/support

Nederlands
ASUSTeK Computer Inc. verklaart hierbij dat dit apparaat voldoet aan de essentiële vereisten en andere relevante bepalingen van de verwante richtlijnen. De volledige tekst van de EU-verklaring van conformiteit is beschikbaar op: www.asus.com/support

Eesti
Käesolevaga kinnitab ASUSTeK Computer Inc. et see seade vastab asjakohaste direktiivide olulistele nõuetele ja teistele asjassepuutuvatele sätetele. EL vastavusdeklaratsiooni täielik tekst on saadaval järgmisel aadressil: www.asus.com/support

Suomi
ASUSTeK Computer Inc. ilmoittaa täten, että tämä laite on asiaankuuluvien direktiivien olennaisista vaatimuksien ja muiden tätä koskevien säästöjen mukainen. EU-yhteismääräysmääräysten koko teksti on luettavissa osoitteessa: www.asus.com/support

Ελληνικά
Με το παρόν, η ASUSTEK Computer Inc. δηλώνει ότι αυτή η συσκευή συμμορφώνεται με τις θεμελιώδεις απαιτήσεις και άλλες σχετικές διατάξεις των Οδηγίων της ΕΕ. Το πλήρες κείμενο της δηλώσης συμμορφότητας είναι διαθέσιμο στη διεύθυνση: www.asus.com/support

Magyar
Az ASUSTEK Computer Inc. ezenel kijelenti, hogy ez az eszköz megfelel a kapcsolódó irányelvek lényeges követelményeinek és egyéb vonatkozó rendelkezésének. Az EU megfelelési nyilatkozat teljes szövege innen tekinthető: www.asus.com/support

Latviski
ASUSTEK Computer Inc. ar šo paziņo, ka šis ierīce atbilst attiecīgo Direktīvu būtiskajām prasībām un citiem citiem saistošajiem nosacījumiem. Pilns ES atbilstības paziņojuma teksts pieejams šeit: www.asus.com/support

Lietuvių
ASUSTEK Computer Inc. šiuo tvirtina, kad šis įrenginys atitinka pagrindinius reikalavimus ir kitas svarbias susijusių direktyvų nuostatas. Visa ES atitikties deklaracijos tekstą galima rasti: www.asus.com/support

Norsk
ASUSTEK Computer Inc. erklærer herved at denne enheten er i samsvar med hovedsakelige krav og andre relevante forskrifter i relaterte direktiver. Fullstendig tekst for EU-samsvarserklæringen finnes på: www.asus.com/support

Safety Guidelines

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C(32°F) to 40°C(104°F). When the device exceeds the maximum temperature, unplug or switch off the device to let it cool down.

安全說明

- 此鍵盤只應在溫度不高於 40° C (104° F) 的環境下使用。
- 安裝錯誤型號的電池可能會導致爆炸。

Notices

Limitation of Liability

Circumstances may arise where because of a default on ASUS part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property, or any other actual and direct damages resulting from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS's suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA, OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
 - This device must accept any interference received including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

CAUTION! The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Compliance Statement of Innovation, Science and Economic Development Canada (ISED)

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3(B)/NMB-3(B)

Déclaration de conformité de Innovation, Sciences et Développement économique Canada (ISED)

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-3(B)/NMB-3(B)

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Innovation, Science and Economic Development Canada (ISED) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has also been evaluated and shown compliant with the ISED RF Exposure limits under portable exposure conditions. (antennas are less than 20 cm of a person's body).

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie rayonnée du dispositif sans fil est inférieure aux limites d'exposition aux radiofréquences d'Innovation, Sciences et Développement économique Canada (ISED). Le dispositif sans fil doit être utilisé de manière à minimiser le potentiel de contact humain pendant le fonctionnement normal.

Cet appareil a également été évalué et montré conforme aux limites d'exposition RF ISED dans des conditions d'exposition portable. (les antennes mesurent moins de 20 cm du corps d'une personne).

Précautions d'emploi de l'appareil :

- Soyez particulièrement vigilant quant à votre sécurité lors de l'utilisation de cet appareil dans certains lieux (les aéroports, les hôpitaux, les stations-service et les garages professionnels).
- Évitez d'utiliser cet appareil à proximité de dispositifs médicaux implantés lors d'un appel téléphonique. Si vous portez un implant électronique (stimulateurs cardiaques, pompes à insuline, neurostimulateurs...), veuillez impérativement respecter une distance minimale de 15 centimètres entre cet appareil et l'implant pour réduire les risques d'interférence.
- Utilisez cet appareil dans de bonnes conditions de réception pour minimiser le niveau de rayonnement. Ce n'est pas toujours le cas dans certaines zones ou situations, notamment les parkings souterrains, les ascenseurs, en train ou en voiture ou tout simplement dans un secteur mal couvert par le réseau.
- Tenez cet appareil à distance du ventre des femmes enceintes et du bas-ventre des adolescents.



REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/REACH.htm>.

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for detailed recycling information in different regions.

Proper disposal



Accessories that came with this product have been designed and verified for the use in connection with this product. Never use accessories for other products to prevent the risk of electric shock or fire.

付属品は本製品専用です。本製品を使用の際には、必ず製品パッケージに付属のものをお使いください。また、付属品は絶対他の製品には使用しないでください。製品破損もしくは、火災や感電の原因となる場合があります。

	Lithium-Ion Battery Warning
	CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

ASUS contact information

ASUSTeK COMPUTER INC.

Address 1F., No. 15, Lide Rd., Beitou Dist., Taipei City 112, Taiwan
Telephone +886-2-2894-3447
Fax +886-2-2890-7798
Web site https://www.asus.com

Technical Support

Telephone +86-21-38429911
Online support https://qr.asus.com/techserv

ASUS COMPUTER INTERNATIONAL (America)

Address 48720 Kato Rd., Fremont, CA 94538, USA
Telephone +1-510-739-3777
Fax +1-510-608-4555
Web site https://www.asus.com/us/

Technical Support

Support fax +1-812-284-0883
Telephone +1-812-282-2787
Online support https://qr.asus.com/techserv

ASUS COMPUTER GmbH (Germany and Austria)

Address Harkortstrasse 21-23, 40880 Ratingen, Germany
Web site https://www.asus.com/de
https://www.asus.com/support/Product/ContactUs/Services/questionform/?lang=de-de

Technical Support

Telephone (DE) +49-2102-5789557
Telephone (AT) +43-1360-2775461
Online support https://www.asus.com/de/support

Официальное представительство в России

Горячая линия Службы технической поддержки в России:
Бесплатный федеральный номер для звонков по России: 8-800-100-2787
Номер для пользователей в Москве: +7(495)231-1999
Время работы: Пн-Пт, 09:00 - 21:00 (по московскому времени)

Официальные сайты ASUS в России:

www.asus.ru
www.asus.com/ru/support

Данное устройство соответствует требованиям Технического регламента Таможенного Союза ТР ТС 020:2011 Электromaгнитная совместимость технических средств утв. решением КТС от 09.12.2011г. №879



电子产品有害物质限制使用标识：图中之数字为产品之环保使用期限。仅指电子产品中含有之有害物质不致发生外泄或突变，从而对环境造成污染或对人体、财产造成严重损害之期限。

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯(PBB)	多溴二苯醚 (PBDE)
印刷电路板及其电子组件	×	○	○	○	○	○
外壳	○	○	○	○	○	○
外部信号连接头及线材	○	○	○	○	○	○
其它	×	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求，然该部件仍符合欧盟指令 2011/65/EU 的规格。
备注：此产品所标示之环保使用期限，系指在一般正常使用状况下。

「產品之限用物質含有情況」之相關資訊，請參考下表：

單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ^{VI})	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
印刷電路板及電子組件	○	○	○	○	○	○
外殼	○	○	○	○	○	○
按鍵	○	○	○	○	○	○
其他及其配件	○	○	○	○	○	○

備註 1. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。

備註 2. “-” 係指該項限用物質為排除項目。

NCC: Taiwan Wireless Statement

低功率射頻器材技術規範

「取得審驗通過之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通訊；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通訊，指依電管法規定作業之無線電通信。低功率射頻器材須符合合法通信或工業、科學及醫療用電波辐射性電機設備之干擾。」
應避免影響附近雷達系統之操作。

VCCI: Japan Compliance Statement

VCCI Class B Statement

警告 VCCI準拠クラスB機器 (日本)

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としています。この装置がラジオやテレビジョン受信機に近接しよて使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

KC: Korea Warning Statement



B급 기기 (가정용 방송통신기자재)

이 기기는 가정용(家庭) 전자파 적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.