


X3 Climbing Aid and Knee Pad. Instructions and Notes



Fitting Instructions and Warranty - goto:
<http://www.urbanclimb.us/instructions-warranty>




Boot Fit

If boot is too big for lower portion of the X3, cut the padding away below a horizontal line through the top of the logos - Top of the arc and top of the X.

Be careful when cutting padding not to dig the knife too far into the shell.

Padding not glued below this line to allow padding removal. Do not re-glue padding.

Only cut padding out if absolutely necessary



1SFA, Guard Widening

The X3 System is designed to fit a wide range of leg sizes. If the X3 Guard standard fit is too narrow it can be widened to fit the operators leg. The plastic has memory and will hold this new width once the guard widening process has been completed correctly.

Place the Guard on top of the supplied dry bags, ensure bags are on a slippery surface to allow guard to stretch open (smooth concrete, polished floors etc). Place one bag under one side and another bag under the other side. (use plastic bags or the like if you do not have access to dry bags).

Choose the end you wish to widen. Stand on and apply constant pressure to one or the other end of the guard (standing near top or bottom end). This will temporarily flatten the guard, and the bags will allow the padding to slide over the floor.

Hold this pressure for 20 seconds



"If we can get one operator over one obstacle, one second faster, we will have achieved our aim"